

1/60

W113  
TM  
1941


TM 11-302

24.5.1941  
WAR DEPARTMENT  
Army

TECHNICAL MANUAL

CHARGING SET SCR-169

December 10, 1941





How well  
you  
have  
done

✓

(US War Dept)


TM 11-302  
C-1

U/113  
15

TECHNICAL MANUAL  
CHARGING SET SCR-160


TM 11:302  
1941

CHANGES  
No. 1



TM 11-302, December 10, 1941, is changed as follows:

★ ★



7L-3250A

FIGURE 16.—Charging set SCR-160—circuit diagram with batteries.

[A.G. 062.11 (4-6-43).] (C 1, May 12, 1943.)

9. Maintenance and repair of power unit PE-( )-43.

\* \* \* \* \*

a. Engine.

\* \* \* \* \*

(2) PE-HB-43.—(a) Lubrication.

\* \* \* \* \*

2. After every 50 hours of operation \* \* \* with fresh oil. (See (3) (a) 2 below.)

\* \* \* \* \*

(3) PE-HC-43, PE-HD-43, PE-HE-43, PE-HF-43, and PE-HG-43.—(a) Lubrication.

\* \* \* \* \*

2. After every 50 hours of operation \* \* \* been tight-ened securely.

\* \* \* \* \*

523912°—43

M558706







**10 $\frac{1}{4}$ .** (Added.) **Power units PE-HF-43 and PE-HG-43.**—These units are identical with power units PE-HD-43 and PE-HE-43. All information in paragraphs 1 to 10 inclusive pertaining to power units PE-HD-43 and PE-HE-43 applies to power units PE-HF-43 and PE-HG-43.

**10 $\frac{1}{2}$ .** (Added.) **Additional information and instructions on power units PE-HD-43, PE-HE-43, PE-HF-43, and PE-HG-43.**—

*a. Ratings and capacities.*—The output ratings of these units is 550 watts at 32 volts and 17 amperes with an engine speed of 2,350 rpm. The output voltage can be varied from 30 to 40 volts by means of the throttle adjustment. It should be adjusted for 32 volts with a full load of 17 amperes (the load is the sum of the current readings on the three ammeters). Additional adjustment should not be required. The gas tank holds 1 $\frac{1}{4}$  gallons. Gasoline consumption is  $\frac{1}{4}$  gallon per hour at full load. While it is preferable to use low test unleaded gasoline, standard issue gasoline may be used. When high test gasoline is used it may be necessary to wrap the gas line with asbestos to prevent the engine heat from causing a vapor lock in the line. When the crankcase is drained, refill it with 1 quart of SAE 20 engine oil. The oil should be changed after about every 50 hours of operation. An excellent way of keeping track of the running time is to keep a record of the amount of gasoline used. On this basis the oil should be changed after every 12 to 15 gallons of gas have been used. When adding gas to the tank, put in a quart at a time. After every 500 hours of operation (when ready for the eleventh oil change, or when 120 to 150 gallons of gas have been used) the carbon and lead should be removed and the valves ground.



b. *Internal connections of generator.*—The two leads from the field coils, the two jumpers between the brush holders, the two leads to the terminal board posts, and the two panel connecting straps must be connected as shown in figure 19 to assure proper functioning of the generator, and the polarized receptacle must be installed as shown to assure proper polarity.




FIGURE 19.—Diagram showing internal connections of generator.

c. *Generator maintenance notes.*—(1) Six bolts (see fig. 20) (manufacturer's part No. 250) are used on some engines to attach the generator adapter (manufacturer's part No. C-641 L) to the engine. Note that two of the bolts are  $\frac{3}{4}$  inch long and four of the bolts are  $\frac{1}{2}$  inch long. The  $\frac{3}{4}$ -inch bolts must be installed in the two holes at the extreme right (2 o'clock and 4 o'clock positions) when the adapter is in place against the engine. Other engines have studs (see fig. 21) mounted on the engine for attachment of the generator adapter.

(2) To remove armature (manufacturer's part No. G-3596), remove brush holder bracket assembly (manufacturer's part No. G-3731); unscrew bolt (manufacturer's part No P-4150) and remove fan; replace bolt (P-4150), screw it in about three or four turns, and tap it gently on the head with a light hammer. This will loosen the armature from the tapered engine shaft. Remove bolt and lift off armature.







d. *Engine and generator parts illustrated.*—The parts for PE-HD-43, PE-HE-43, PE-HF-43, and PE-HG-43 are illustrated in figures 20, 21, and 22.





FIGURE 20.—Generator parts.




TL-4787

FIGURE 21.—Engine parts.









TL-4786

FIGURE 22.—Piston, carburetor, and magneto parts.



**11. List of replacement parts.**—A list of replacement parts of power unit PE-( )-43 and panel BD-( )-61 is given below (*a* to *au*, incl.).

| A                        | B                                                         | C                                                                  | D                                                                  | E        | F                                                                                                          |
|--------------------------|-----------------------------------------------------------|--------------------------------------------------------------------|--------------------------------------------------------------------|----------|------------------------------------------------------------------------------------------------------------|
| Item<br>reference<br>No. | Name of item                                              | PE-HA-43<br><br>Homelite<br>Corporation, Port<br>Chester,<br>N. Y. | PE-HB-43<br><br>United States Motors<br>Corporation, Oshkosh, Wis. | PE-HC-43 | PE-HD-43,<br>PE-HE-43,<br>PE-HF-43,<br>PE-HG-43<br><br>Climax Engineering<br>Corporation,<br>Clinton, Iowa |
| 40                       | Piston, oil pump                                          |                                                                    | RA-366                                                             | 63207    |                                                                                                            |
| 46                       | Spring, oil pump, small                                   |                                                                    | RA-377                                                             | 26413    | 26413.                                                                                                     |
| 46A                      | Screw, 5/16"—24 x 3/4" hex. hd.                           |                                                                    |                                                                    |          | 90950.                                                                                                     |
| 46B                      | Lockwasher, 5/16", for item 46A                           |                                                                    |                                                                    |          | 90366.                                                                                                     |
| 47                       | Retainer, oil pump check ball                             |                                                                    | RA-368-A                                                           |          |                                                                                                            |
| 59                       | Cylinder                                                  | 11399                                                              | RA-1-F                                                             |          |                                                                                                            |
| 59A                      | Tube, breather                                            |                                                                    |                                                                    |          | 69751.                                                                                                     |
| 60                       | Valve, intake                                             |                                                                    | RA-20-A                                                            | 68923    | 68923.                                                                                                     |
| 79                       | Shield, cylinder                                          | 10555                                                              |                                                                    | 62335    | 22142.                                                                                                     |
| 79A                      | Guide, air, front (intake manifold<br>side).              |                                                                    |                                                                    |          | 22146.                                                                                                     |
| 79B                      | Guide, intake valve (not illus-<br>trated).               |                                                                    |                                                                    |          | 61348.                                                                                                     |
| 79C                      | Guide, exhaust valve (not illus-<br>trated).              |                                                                    |                                                                    |          | 61955.                                                                                                     |
| k                        | Louvre plate assembly                                     |                                                                    | RA-1235-2                                                          |          |                                                                                                            |
| 85                       | Bearing, crankshaft, ball                                 |                                                                    |                                                                    | 99157    | 99157.                                                                                                     |
| 85A                      | Screw, bearing retainer                                   |                                                                    |                                                                    |          | 91648.                                                                                                     |
| 85B                      | Lockwasher, bearing retainer<br>screw.                    |                                                                    |                                                                    |          | 91865.                                                                                                     |
| 86                       | Oil seal, crankshaft bearing                              |                                                                    |                                                                    | 99175    | 99175.                                                                                                     |
| 106                      | Plug, spark, 18 mm x 1.5 mm<br>thread.                    | 3H4413-7                                                           | RA-359                                                             | 89572    | 89572.                                                                                                     |
| 106A                     | Gasket, spark plug                                        |                                                                    |                                                                    |          | 27090.                                                                                                     |
| 107                      | Screw, cylinder                                           | 10404                                                              |                                                                    |          |                                                                                                            |
| 126                      | Lever, governor                                           |                                                                    | RA-55                                                              |          | 99917.                                                                                                     |
| 126A                     | Pin, cotter, 1/16" x 7/8" (for item<br>126).              |                                                                    |                                                                    |          | 92286.                                                                                                     |
| 127                      | Spring, governor                                          |                                                                    | RA-183                                                             |          |                                                                                                            |
| 369A                     | Cable, ignition (not included in<br>assembly <i>aa</i> ). |                                                                    |                                                                    | 29147    | 29147.                                                                                                     |
| 369B                     | Cable, ignition                                           |                                                                    |                                                                    |          | 99902.                                                                                                     |
| 370                      | Brush holder, magneto                                     | 15309                                                              |                                                                    |          |                                                                                                            |
| 386                      | Valve, oil return                                         |                                                                    |                                                                    | 89307    | 89307.                                                                                                     |





| A                        | B                                                                                      | C                                                                  | D                                                                  | E        | F                                                                                                            |
|--------------------------|----------------------------------------------------------------------------------------|--------------------------------------------------------------------|--------------------------------------------------------------------|----------|--------------------------------------------------------------------------------------------------------------|
| Item<br>reference<br>No. | Name of item                                                                           | PE-HA-43<br><br>Homelite<br>Corporation, Port<br>Chester,<br>N. Y. | PE-HB-43<br><br>United States Motors<br>Corporation, Oshkosh, Wis. | PE-HC-43 | PE-HD-43,<br>PE-HE-43,<br>PE-HF-43,<br>PE-HG-43<br><br>Climax Engineer-<br>ing Corporation,<br>Clinton, Iowa |
| 386A.....                | Clamp, for ignition cable on air<br>guide.                                             |                                                                    |                                                                    |          | 23581.                                                                                                       |
| 386B.....                | Screw, 10-32 x 5/16" round head,<br>for cable clamp.                                   |                                                                    |                                                                    |          | 90078.                                                                                                       |
| 386C.....                | Nut, 10-32 hex, for cable clamp<br>screw.                                              |                                                                    |                                                                    |          | 90355.                                                                                                       |
| 386D.....                | Lock washer, 13/64" x 1/16" x 3/64",<br>(for items 386C and 386E).                     |                                                                    |                                                                    |          | 92290.                                                                                                       |
| 386E.....                | Screw, round head, contact block<br>mounting.                                          |                                                                    |                                                                    |          | 91406.                                                                                                       |
| 386F.....                | Rivet, for air guide                                                                   |                                                                    |                                                                    |          | 36436.                                                                                                       |
| ah.....                  | Fuel tank assembly                                                                     |                                                                    | RA-2429-1                                                          |          |                                                                                                              |
| 397.....                 | Washer, fuel tank cap.                                                                 |                                                                    | RA-311                                                             |          | 65053 or C-589A.                                                                                             |
| 405.....                 | Screw, fuel tank bracket                                                               |                                                                    | 4-G-05                                                             | 91229    | 91247.                                                                                                       |
| 407.....                 | Nut and bolt, fuel tank strap                                                          |                                                                    |                                                                    | 91568    | 91568.                                                                                                       |
| 407A.....                | Bolt 1/4"-20 x 1 1/2" round head<br>(for item 403).                                    |                                                                    |                                                                    |          | 91257.                                                                                                       |
| 407B.....                | Nut, 1/4"-20 square head (for<br>item 403).                                            |                                                                    |                                                                    |          | 90970.                                                                                                       |
| ak.....                  | Base assembly                                                                          |                                                                    | RA-1015-5                                                          |          |                                                                                                              |
| 449.....                 | Housing, blower                                                                        |                                                                    | RA-104-C                                                           | 29098    | 1 99929 or 2 89521.                                                                                          |
| 494.....                 | Receptacle                                                                             | 15100                                                              |                                                                    | 10108    | 10108.                                                                                                       |
| 494A.....                | Standard screw, 6-32 x 3/8" round<br>head brass, (for item 494).                       |                                                                    |                                                                    |          |                                                                                                              |
| 494B.....                | Standard lock washer, for 6-32<br>screw (for item 494A).                               |                                                                    |                                                                    |          |                                                                                                              |
| 494C.....                | Strap connection, (for item 494)                                                       |                                                                    |                                                                    |          | C-463-A.                                                                                                     |
| 495.....                 | Nut, molder terminal                                                                   | 15071                                                              |                                                                    |          |                                                                                                              |
| 500.....                 | Bracket, terminal panel, right<br>hand.                                                |                                                                    |                                                                    | SC-34    | C-394-D.                                                                                                     |
| 500A.....                | Standard screw, 10-32 x 1/2" (round<br>head) brass machine (for items<br>499 and 500). |                                                                    |                                                                    |          |                                                                                                              |
| 500B.....                | Standard nut, 10-32 brass hex.<br>(for item 500A).                                     |                                                                    |                                                                    |          |                                                                                                              |
| 500C.....                | Lock washer (for item 500A)                                                            |                                                                    |                                                                    |          | 1910.                                                                                                        |
| 501.....                 | Cable, negative, long                                                                  | 11590                                                              |                                                                    |          | SP-152.                                                                                                      |
| 502.....                 | Cable, positive, short                                                                 | 11589                                                              |                                                                    |          | SP-153.                                                                                                      |
| 503.....                 | Cable, regulator to terminal plate                                                     | 15051                                                              |                                                                    |          |                                                                                                              |

1 Used with PE-HD-43 and PE-HE-43.

2 Used with PE-HF-43 and PE-HG-43.



## CHARGING SET SCR-169

TM 11-302

C 1

| A                        | B                                                                    | C                                                                       | D                                                                  | E              | F                                                                                                            |
|--------------------------|----------------------------------------------------------------------|-------------------------------------------------------------------------|--------------------------------------------------------------------|----------------|--------------------------------------------------------------------------------------------------------------|
| Item<br>reference<br>No. | Name of item                                                         | PE-HA-43<br><br>Homelite<br>Corpora-<br>tion, Port<br>Chester,<br>N. Y. | PE-HB-43<br><br>United States Motors<br>Corporation, Oshkosh, Wis. | PE-HC-43       | PE-HD-43,<br>PE-HE-43,<br>PE-HF-43,<br>PE-HG-43<br><br>Climax Engineer-<br>ing Corporation,<br>Clinton, Iowa |
| 505.....                 | Binding post, terminal.....                                          |                                                                         |                                                                    | 45.....        | 45.                                                                                                          |
| 505A.....                | Lock washer (for item 505).....                                      |                                                                         |                                                                    |                | 1910.                                                                                                        |
| 505B.....                | Washer, brass (for item 505).....                                    |                                                                         |                                                                    |                | 10S.                                                                                                         |
| 505C.....                | Standard nut, hex. 10-32 brass,<br>(for item 505).....               |                                                                         |                                                                    |                |                                                                                                              |
| at.....                  | Armature Assembly.....<br>Includes items.....                        | 10758.....<br>506, 507.....                                             |                                                                    | G-3596.....    | G-3596.                                                                                                      |
| 506.....                 | Armature.....                                                        | 15155.....                                                              |                                                                    |                |                                                                                                              |
| 507.....                 | Fan and bushing assembly.....                                        |                                                                         |                                                                    | G-3597.....    | G-3597.                                                                                                      |
| 507A.....                | Bolt, fan.....                                                       |                                                                         |                                                                    |                | P-4150.                                                                                                      |
| 507B.....                | Lock washer, fan bolt.....                                           |                                                                         |                                                                    |                | P-3849.                                                                                                      |
| au.....                  | Field frame and coil assembly.....<br>Includes items.....            | 10766.....                                                              | 508, 509.....                                                      |                |                                                                                                              |
| 508.....                 | Casting, field frame.....                                            |                                                                         |                                                                    | P-5746.....    | P-5746.                                                                                                      |
| 508A.....                | Studs, field frame.....                                              |                                                                         |                                                                    |                | C-554-C.                                                                                                     |
| 508B.....                | Standard nuts, 1/4"-28 NF hex.<br>(for item 508A).....               |                                                                         |                                                                    |                |                                                                                                              |
| 508C.....                | Lock washers (for item 508A).....                                    |                                                                         |                                                                    |                | 1225.                                                                                                        |
| 509.....                 | Coil assembly, field.....                                            |                                                                         |                                                                    | G-3599.....    | G-3599.                                                                                                      |
| *                        | * * *                                                                | *                                                                       | *                                                                  | *              | *                                                                                                            |
| 514.....                 | Grommet, insulating.....                                             |                                                                         |                                                                    | GR-A-5848..... | GR-A-5848.                                                                                                   |
| 514A.....                | Shim, field pole.....                                                |                                                                         |                                                                    |                | SM-A-6175.                                                                                                   |
| av.....                  | Brush assembly.....                                                  | 11476.....                                                              |                                                                    |                |                                                                                                              |
| *                        | * * *                                                                | *                                                                       | *                                                                  | *              | *                                                                                                            |
| 517.....                 | Holder, brush.....                                                   | 15120.....                                                              |                                                                    | G-3731.....    | G-3731.                                                                                                      |
| 517A.....                | Screw, brush holder.....                                             |                                                                         |                                                                    |                | P-3851.                                                                                                      |
| 518.....                 | Screw, brush holder.....                                             |                                                                         |                                                                    | P-4581.....    | P-4581.                                                                                                      |
| *                        | * * *                                                                | *                                                                       | *                                                                  | *              | *                                                                                                            |
| 532.....                 | Cover, generator.....                                                |                                                                         |                                                                    | P-5743.....    | P-5743.                                                                                                      |
| 532A.....                | Name plate, instruction.....                                         |                                                                         |                                                                    |                | C-401-S.                                                                                                     |
| 532B.....                | Standard pin, escutcheon, 14 1/4"<br>brass.....                      |                                                                         |                                                                    |                |                                                                                                              |
| 532C.....                | Name plate, power unit.....                                          |                                                                         |                                                                    |                | C-401-AS.                                                                                                    |
| 533.....                 | Cover, generator end.....                                            |                                                                         |                                                                    | P-5744.....    | P-5744.                                                                                                      |
| *                        | * * *                                                                | *                                                                       | *                                                                  | *              | *                                                                                                            |
| 535.....                 | Lock washer, end plate screw.....                                    | 10485.....                                                              |                                                                    | P-3515.....    | P-3852.                                                                                                      |
| 535A.....                | Screw, end cover.....                                                |                                                                         |                                                                    |                | P-5763.                                                                                                      |
| 535B.....                | Lock washer, end cover screw.....                                    |                                                                         |                                                                    |                | P-3515.                                                                                                      |
| 536.....                 | Adapter, generator.....                                              |                                                                         |                                                                    | P-I-550-A..... | C-641-L.                                                                                                     |
| 536A.....                | Stud, for mounting item 536.....                                     |                                                                         |                                                                    |                | 23537.                                                                                                       |
| 536B.....                | Standard nut, 5/16"-24 N. F.<br>hex. for item 536A.....              |                                                                         |                                                                    |                |                                                                                                              |
| 536C.....                | Standard cap screw, 5/16"-24<br>hex. hd., for mounting item 536..... |                                                                         |                                                                    |                |                                                                                                              |
| 536D.....                | Lock washer (for item 536A or<br>536C).....                          |                                                                         |                                                                    |                | 1330.                                                                                                        |
| 537.....                 | Screw, shell.....                                                    |                                                                         |                                                                    | P-5734.....    | P-5734.                                                                                                      |
|                          | * * *                                                                | *                                                                       | *                                                                  | *              | * *                                                                                                          |





| A                        | B                                                                      | C                                                                       | D                                                                  | E             | F                                                                                                            |
|--------------------------|------------------------------------------------------------------------|-------------------------------------------------------------------------|--------------------------------------------------------------------|---------------|--------------------------------------------------------------------------------------------------------------|
| Item<br>reference<br>No. | Name of item                                                           | PE-HA-43<br><br>Homelite<br>Corpora-<br>tion, Port<br>Chester,<br>N. Y. | PE-HB-43<br><br>United States Motors<br>Corporation, Oshkosh, Wis. | PE-HC-43      | PE-HD-43,<br>PE-HE-43,<br>PE-HF-43,<br>PE-HG-43<br><br>Climax Engineer-<br>ing Corporation,<br>Clinton, Iowa |
| 541.....                 | Skid base assembly.....                                                |                                                                         |                                                                    | SC-31.....    | <sup>1</sup> C-576-B or <sup>2</sup> C-<br>576-J.                                                            |
| 541A.....                | Support, generator.....                                                |                                                                         |                                                                    |               | C-643-AG.                                                                                                    |
| 541B.....                | Spacer, generator support (center).....                                |                                                                         |                                                                    |               | C-434-C.                                                                                                     |
| 541C.....                | Standard cap screw, 3/8"-16 N. C.<br>x 1 1/2" hex. head for item 541B. |                                                                         |                                                                    |               |                                                                                                              |
| 541D.....                | Standard lock washer, 3/8" (for<br>item 541C).                         |                                                                         |                                                                    |               |                                                                                                              |
| 541E.....                | Spacer, generator support (ends).....                                  |                                                                         |                                                                    |               | C-434-B.                                                                                                     |
| 541F.....                | Lock washer (for item 541E).....                                       |                                                                         |                                                                    |               | 1218.                                                                                                        |
| 541G.....                | Standard nut, 5/16"-18 N. C. hex.<br>head (for item 541E).             |                                                                         |                                                                    |               |                                                                                                              |
| 542.....                 | Mounting, rubber.....                                                  |                                                                         |                                                                    | DA-1090-70.   | DA-1090.                                                                                                     |
| 542A.....                | Handle, carrying "U" (see fig. 6).....                                 |                                                                         |                                                                    |               | C-612-A.                                                                                                     |
| 542B.....                | Lock nut, carrying handle.....                                         |                                                                         |                                                                    |               | C-425-A.                                                                                                     |
| 542C.....                | Angle iron (for item 540).....                                         |                                                                         |                                                                    |               | 2522.                                                                                                        |
| 542D.....                | Plate, back (for item 540).....                                        |                                                                         |                                                                    |               | C-567.                                                                                                       |
| 543.....                 | Handle, crate.....                                                     |                                                                         |                                                                    | 2082-J-4..... | 108.                                                                                                         |
| *                        | *                                                                      | *                                                                       | *                                                                  | *             | *                                                                                                            |

[A. G. 062.11 (4-6-43).] (C1, May 12, 1943.)

<sup>1</sup> Used with PE-HD-43 and PE-HE-43.<sup>2</sup> Used with PE-HF-43 and PE-HG-43.

**12. (Added.) Tools and spare parts for power units PE-HD-43, PE-HE-43, PE-HF-43, and PE-HG-43.**—The following tools and spare parts are furnished with each of the above power units and are packed in the tool box on the skid base. The manufacturer is Climax Engineering Company, Clinton, Iowa.

1 set of tools as follows:

- 1 6-inch gas plier (thin nose).
- 1 8-inch screw driver.
- 1 9-inch carbon scraper.
- 1  $\frac{3}{8}$ - by  $\frac{1}{16}$ -inch open-end wrench.
- 1  $\frac{1}{2}$ - by  $\frac{9}{16}$ -inch open-end wrench.
- 1  $1\frac{1}{32}$ - by  $1\frac{1}{16}$ -inch open-end wrench.
- 1  $\frac{5}{8}$ - by  $\frac{3}{4}$ -inch open-end wrench.
- 1 29157 wheel puller.
- 1  $1\frac{1}{4}$ -inch manifold wrench ( $\frac{3}{16}$ -inch thick).
- 1 1-inch spark plug wrench, 68652.
- 1  $\frac{1}{4}$ -inch magneto wrench with 0.002-inch gap gages.
- 1  $\frac{7}{16}$ -inch connecting rod wrench.

- 1 set spare parts as follows:
  - 2 89572 spark plugs (Champion type 6M)
  - 1 29652 condenser.
  - 1 69780 contact block assembly.
- 1 envelope containing—
  - 4 G-2963 generator brushes.
- 1 envelope containing—
  - 1 63238 contact point screw.
  - 1 66987 base gasket.
  - 1 66457 magneto plate gasket 0.015-inch thick.
  - 1 66537 magneto plate gasket 0.009-inch thick.
  - 1 66527 magneto plate gasket 0.005-inch thick.
  - 1 69004 cylinder head gasket.
  - 1 65617 valve cover plate gasket.
  - 1 68477 gasoline filter gasket.
  - 1 27016 air cleaner gasket.
  - 1 68987 carburetor gasket.
  - 1 68877 inlet valve seat gasket.
  - 1 68897 venturi gasket.
  - 1 68887 needle valve packing.
  - 1 68857 carburetor body gasket.
  - 1 69754 contact point and spring.
  - 1 65053 gasoline tank cap gasket.
  - 1 C-589A fuel tank cap gasket.
- 1 starting rope.

[A. G. 062.11 (4-6-43).] (C 1, May 12, 1943.)

BY ORDER OF THE SECRETARY OF WAR:

G. C. MARSHALL,  
*Chief of Staff.*

OFFICIAL:

J. A. ULIO,  
*Major General,*  
*The Adjutant General.*









TECHNICAL MANUAL }  
No. 11-302 }

WAR DEPARTMENT,  
WASHINGTON, December 10, 1941.

## CHARGING SET SCR-169

Prepared under direction of the  
Chief Signal Officer

|                                                     | Paragraph |
|-----------------------------------------------------|-----------|
| Use.....                                            | 1         |
| Description.....                                    | 2         |
| Major units.....                                    | 3         |
| Installation for service.....                       | 4         |
| Operation.....                                      | 5         |
| Removal from service.....                           | 6         |
| Function of parts.....                              | 7         |
| Care of set.....                                    | 8         |
| Maintenance and repair of power unit PE-( )-43..... | 9         |
| Troubles and their remedies.....                    | 10        |
| List of replacement parts.....                      | 11        |

**1. Use.**—The charging set SCR-169 is intended primarily to provide a portable means for charging storage batteries where an internal-combustion engine-driven generator with a d-c power output of not more than 550 watts at 32 volts is required. This set may be readily transported by truck or wagon and may be used in any location where sufficient space to install it is available.

**2. Description.**—Each charging set SCR-169 consists of one power unit PE-( )-43, one panel BD-( )-61, and one cord CD-107. The power unit and the panel are manufactured under the general nomenclature of power unit PE-( )-43 and panel BD-( )-61, in accordance with so-called “performance specifications” which allow the various manufacturers to furnish equipment of their own design provided certain requirements as to performance are satisfied. The parentheses in the nomenclature are replaced on name plates by code letters identifying the particular design furnished on any order, for example, PE-HC-43. These letters differentiate each design supplied under the specifications from the various other models produced. At the time of printing the following power units and panels for charging set SCR-169 have been procured: Power units PE-HA-43, PE-HB-43, PE-HC-43, PE-HD-43, and PE-HE-43; and panels BD-LL-61, BD-LM-61, BD-LN-61, BD-LO-61, and BD-LP-61. In the field when not in use the cord CD-107 is normally carried in the panel BD-( )-61; this allows the set to be carried in two sections.

a. One part is the power unit which consists of a wooden packing crate containing the engine-generator unit and a box for carrying the

\*This pamphlet supersedes TR 1215-6, July 14 1932.

tools and spare parts, both of which are attached to a common base which also forms the bottom of the packing crate (fig. 17). The dimensions of the power units PE-( )-43 are as follows:

|               | Width<br>(inches) | Length<br>(inches) | Height<br>(inches) | Height<br>without<br>crate<br>(inches) | Weight<br>without<br>crate<br>(pounds) | Weight<br>including<br>crate<br>(pounds) |
|---------------|-------------------|--------------------|--------------------|----------------------------------------|----------------------------------------|------------------------------------------|
| PE-HA-43----- | 17¾               | 25¾                | 25¾                | 21                                     | 169                                    | 185                                      |
| PE-HB-43----- | 20                | 25¾                | 22¾                | 18½                                    | 110½                                   | 150                                      |
| PE-HC-43----- | 22½               | 20½                | 24                 | 22                                     | 115                                    | 153                                      |
| PE-HD-43----- | 20¾               | 22¾                | 22½                | 20½                                    | 110                                    | 150                                      |
| PE-HE-43----- | 20¾               | 22¾                | 22½                | 20½                                    | 110                                    | 150                                      |

b. The second part is the panel BD-( )-61 which consists of a sheet steel cabinet in which is permanently mounted an insulating panel board with its electrical measuring instruments, rheostats, switches, and terminals. Dimensions of panels are approximately as follows: width, 10¼ inches; length, 22¼ inches; height, 22½ inches; and weight 100 pounds.

c. The third part is the cord CD-107 (fig.15), which is used to connect the power unit to the panel (par. 3c).

**3. Major units.**—*a. Power unit PE-( )-43.*—(1) *Power unit PE-HA-43.*—(a) This engine-generator unit is of commercial design, manufacturer's type *D*, manufactured by the Homelite Corporation, Port Chester, N. Y. It consists of an internal-combustion gasoline engine, generator, voltage regulator, and fuel supply tank, built as a single unit and inclosed in one case. The unit is fastened to a wooden base by shock mountings.

(b) The single-cylinder two-cycle engine is inverted, air-cooled, and of the removable-cylinder type. The engine develops 1½ horsepower, has a stroke of 2¾ inches, and a bore of 2¾ inches. The engine end of the main shaft is mounted on ball bearings. The carburetor is a commercial Tillotson type MS-52-A. Ignition is provided by means of a Bosch high-voltage magneto. The spark plug is 18 millimeters in diameter with 1½-millimeter pitch thread. No governor is used as the voltage regulator automatically controls the fuel feed. The 1-gallon fuel tank is contained in the base and provides sufficient fuel for 5 hours' operation. Constructional details of the unit are shown in figure 1.

(c) The six-pole shunt-wound generator and the engine are contained in the same case. The generator armature is mounted on the main shaft of the engine. The entire main shaft runs in ball bearings.

(2) *Power unit PE-HB-43.*—(a) This unit is manufactured by United States Motors Corporation, Oshkosh, Wis. It is composed of a Lauson type RAY gasoline engine and a two-pole, 550-watt, 32-volt, 2,000-rpm d-c generator, manufactured by Brown and Brockmeyer Co., Dayton, Ohio. The unit is mounted on a wooden base by special rubber mountings.

(b) The engine is a single-cylinder,  $1\frac{1}{2}$ -horsepower, four-cycle, L-head, air-cooled unit, with a  $2\frac{1}{4}$ -inch bore and a  $2\frac{1}{4}$ -inch stroke. It is lubricated by a supply of oil, which should be of good quality with a viscosity of SAE 20, in the crankcase. The carburetor is a float-feed type which has only one adjustment, the needle valve for fuel regulation (figs. 2 and 3). The magneto is an Eisemann model 71-M, which is incorporated in the flywheel. The governor is an inclosed mechanical type, the adjustment of which is locked by a lock nut.

(c) The generator is a d-c shunt-wound two-pole type with a terminal board mounted on its frame. The voltage is controlled by the operating speed of the engine.

(3) *Power unit PE-HC-43.*—(a) This unit is manufactured by United States Motors Corporation, Oshkosh, Wis., and is made up of a Briggs and Stratton model AP type No. 25466 gasoline engine and a 32-volt, 550-watt, 2,350 rpm generator manufactured by Pioneer Gen-E-Motor Corporation, mounted on a wooden base by special shock mountings.

(b) The engine is a single-cylinder,  $1\frac{1}{2}$  horsepower, four-cycle, L-head, air-cooled unit with a  $2\frac{1}{4}$ -inch bore and a  $2\frac{1}{4}$ -inch stroke (figs. 4 and 5). Lubrication is accomplished by means of a supply of oil, which should be of good quality with a viscosity of SAE 20, in the crankcase. The carburetor is an especially designed adjustable float-feed type. The air cleaner is to protect the engine from dust and dirt. The governor is an adjustable mechanical type, fully inclosed, which runs in oil. It has been tested and set for an operating speed of 2,350 rpm under full load. Ignition is accomplished by a magneto which together with contact points and capacitor is contained in the flywheel.

(c) The generator is a d-c, shunt-wound, four-pole type with a terminal panel mounted on its frame. The voltage is controlled by the operating speed of the engine.

(4) *Power units PE-HD-43 and PE-HE-43.*—(a) These units are identical and are manufactured by Climax Engineering Corporation, Clinton, Iowa. Each is made up of a Briggs and Stratton model AP gasoline engine and a generator manufactured by Pioneer Gen-E-






FIGURE 1.—Power unit P.E-HA-43—sectional view.




FIGURE 1.—Power unit PE-HA-43—sectional view—Continued.




FIGURE 1.—Power unit PE-HA-43—sectional view.—Continued.

7L-3216-1





FIGURE 1.—Power unit PE-HA-43—sectional view—Continued.

Motor Corporation, mounted on a wooden base by special shock mountings (fig. 6).

(b) The engine is a single-cylinder,  $1\frac{1}{2}$ -horsepower, four-cycle, L-head, air-cooled unit with a  $2\frac{1}{4}$ -inch bore and a  $2\frac{1}{4}$ -inch stroke. Lubrication is accomplished by means of a supply of oil, which should be of good quality with a viscosity of SAE 20, in the crankcase. The carburetor is a Tillotson adjustable float-feed type. An air cleaner is used to protect the engine from dust and dirt. The governor is an



TL-3173


FIGURE 2.—Power unit PE-HB-43—front view.

adjustable mechanical type, fully inclosed, which runs in oil. Ignition is accomplished by a magneto which together with contact points and capacitor is contained in the flywheel.

(c) The generator is a d-c shunt-wound four-pole type with a terminal panel mounted on its frame. The voltage is controlled by the operating speed of the engine.

b. Panel BD-( )-61.—(1) Panel BD-LL-61.—The insulated panel board is made of  $\frac{1}{2}$ -inch asbestos wood and is permanently fastened to the steel case (figs. 7 and 8). A voltmeter IF-47, 0-50 volts, direct current; three ammeters IF-16, 0-10 amperes, direct current, marked "1," "2," and "3"; a magnetic contactor switch; an auto-

matic switch; three rheostat control handles marked "1," "2," and "3"; and three fused, double-pole, single-throw switches marked "BAT 1," "BAT 2," and "BAT 3" are mounted on the face of the panel. Three rheostats of 12.5 ohms each are mounted on the back of the insulating panel (fig. 9). The ammeter, rheostat, and switch in each circuit are marked with the same number. A circuit diagram of the panel is shown in figure 10.



TL-3174

FIGURE 3.—Power unit PE-HB-43—rear view.

(2) *Panels BD-LM-61, BD-LN-61, BD-LO-61, and BD-LP-61.*—The insulated panel board is made of  $\frac{1}{2}$ -inch black phenolic plate, fastened to the steel case (figs. 8 and 12). A voltmeter IF-47, 0-50 volts, direct current; three ammeters IF-17, 0-15 amperes, direct current, marked "1," "2," and "3"; an inclosed magnetic contactor switch; an inclosed reverse current relay (automatic switch); three rheostat control handles marked "1," "2," and "3"; and three inclosed 10-ampere double-pole single-throw circuit-breakers marked "BAT 1," "BAT 2," and "BAT 3" are mounted on the face of the panel. Three rheostats of 12.5 ohms each are mounted on the back of the panel (fig. 13). The ammeter, rheostat, and circuit-breaker in

each circuit are marked with the same number. A circuit diagram for these panels is shown in figure 11.

c. *Cord CD-107*.—This cord connects the panel to the power unit as shown in figure 14. It is 15 feet long and consists of two conductors





FIGURE 4.—Power unit PE-HC-43—front view.

twisted together with an outer covering of waterproof cotton braid. Latest procurements of cord CD-107 have rubber covering over the two twisted leads (fig. 15). Each conductor consists of 104 strands of No. 30 B. & S. gage annealed copper wire insulated with new code rubber and covered with a close cotton braid. One end of the cord is equipped with two hook-type terminals marked + and —, respec-

tively. The other end of the cord is equipped with a 15-ampere polarized plug.

**4. Installation for service.**—*a. General.*—(1) *Transportation.*—The bulk and weight of the parts comprising this set require suitable transportation for its movement.



TL-3181

FIGURE 5.—Power unit PE-HC-43—engine details.

(2) *Personnel.*—Two men are required to unload the equipment and to set it up for operation. These men, in addition to being qualified storage battery men, should be especially trained in the care, maintenance, installation, testing, and inspecting for serviceability of the component parts of the set.

(3) *Location.*—The location of the set should be one that provides a reasonable amount of protection against the elements, is centrally



situated with respect to the territory served by the set, and is at least 50 feet from any radio set.

*b. Preparing set for service.*—Reference should be made to figure 14 in connection with these instructions. Place the power unit in a level position where there is a good circulation of air. Unfasten the four trunk catches located at the bottom corners of the packing crate





FIGURE 6.—Power unit PE-HD-43 or PE-HE-43—rear view.

and remove the top part of the crate. Place the panel in the desired position. Using the cord CD-107, connect the + and - hook-type terminals to the respective binding posts marked "GEN+" and "GEN-" located at the top of the insulated panel board. Insert the plug of the cord in the receptacle provided on the power unit PE-43. The receptacles on the various units are located as follows:

(1) PE-HA-43 in the power unit case just to the right of the spark plug.



**TL-3214**

**FIGURE 7.**—Panel BD-LL-61—front view.

(2) PE-HB-43, PE-HC-43, PE-HD-43, and PE-HE-43 in the terminal panel mounted on the generator frame.

*c. Tests and inspections for serviceability and precautions to be observed.*—(1) Before placing the set in operation see that the—

(a) Power unit is level and firmly seated and that the panel is upright and level.




FIGURE 8.—Panel BD-( )-61 ready for shipment.

(b) Power unit is to operate in an area with good air circulation to prevent danger to personnel.


(c) Electrical connections are made with proper polarity, and that all wires are protected from each other and are so placed that personnel cannot injure themselves by accidental contact.

(d) Fuel tank is filled and, if required, oil is mixed with the gasoline as specified in paragraph 5.

(e) Oil is up to correct level, if specified, as in paragraph 5.

(2) Remove any section of pipe or hose that may be attached to the muffler exhaust. If this is not done, the output will be reduced.

(3) Do not fill the fuel tank above the bottom of the filler spout.



TL-3215


FIGURE 9.—Panel BD-LL-61—rear panel view.

(4) Do not permit fuel to run too low in the tank; fill after  $3\frac{1}{2}$  hours of operation to obviate the necessity of readjusting the carburetor.

(5) See that carburetor is properly adjusted for starting.


(6) Readjust the carburetor, if no governor is used, whenever the charging rate is changed.

(7) Always run the generator for about 5 minutes before connecting it to the load.



TL-1258

FIGURE 10.—Panel BD-LL-61—circuit diagram.



TL-3176

FIGURE 11.—Panel BD-LM-61, BD-LN-61, BD-LO-61, or BD-LP-61—circuit diagram.




FIGURE 12.—Panel BD-LO-61—front view.






FIGURE 13.—Panel BD-LO-61—rear panel view.




FIGURE 14.—Charging set SCR-169 set up for operation






FIGURE 15.—Cord CD-107.

**5. Operation.**—*a. Starting and stopping engine.*—The operation of the engine is, in general, the same as that of any gasoline engine.

(1) To start the engine, proceed as follows:

(a) *PE-HA-43.*

1. Fill the fuel tank with gasoline and oil. Use  $\frac{1}{2}$  pint of SAE 40 motor oil mixed with each gallon of gasoline (par. 9a(1) (a)). Always mix the gasoline and oil before filling the tank. **Caution:** Do not use ethyl (red) gasoline. The slow-burning properties of ethyl gasoline cause preignition in two-cycle engines (ignition of the gasoline by the still burning exhaust gas before compression is completed) resulting in engine overheating and loss of power.
2. Pull the choke plunger out (fig. 1).
3. Insert a few drops of gasoline through the screened opening in the choke body.
4. Push the choke plunger in.

5. Wind the starting rope clockwise on the flanged starting pulley and start the engine by pulling sharply on the rope.
6. Pull the choke plunger out when the motor starts.
7. Adjust the carburetor adjustment underneath the carburetor until the engine runs smoothly at normal operating temperature under load.

(b) *PE-HB-43*.

1. Fill the fuel tank with *regular* gasoline. **Caution:** Do not use ethyl (red) gasoline. Do not mix oil with the gasoline.
2. Fill the crankcase with a good quality oil of viscosity SAE 20 to the top of the filler fitting.

NOTE.—For heavy summer duty, involving full load conditions for long periods of time, oil of viscosity SAE 30 may be used instead of SAE 20.

3. Open the gasoline shut-off valve located on the bottom of the fuel tank at the point where the fuel line is connected to the tank (fig. 2) and allow the carburetor float chamber to fill up.
4. Slip the knotted end of the starter rope into the notch of the starter pulley and wind it around the pulley three or four times.
5. Pull the choke rod to choke the carburetor (fig. 3).
6. Pull the starter rope with a quick, steady pull to spin and start motor. The motor should start immediately and the choke should gradually be released as the engine warms up.

(c) *PE-HC-43, PE-HD-43, PE-HE-43*.

1. Fill the fuel tank with gasoline. **Caution:** Do not use ethyl (red) gasoline. Do not mix oil with the gasoline.
2. Fill the crankcase with a good quality oil of viscosity SAE 20 to the top of the filler fitting.
3. Open the gasoline shut-off valve located at the top of the sediment cup (fig. 4) and allow the carburetor float chamber to fill up.
4. Slip the knotted end of the starter rope into the notch of the starter pulley and wind it around the pulley three or four times.
5. Pull the choke rod to close the choke partly (fig. 5).
6. Pull the starter rope with a quick, steady pull to spin and start motor. The motor should start immediately and the choke should gradually be released as motor warms up.

(2) To stop the engine, proceed as follows:

- (a) *PE-HA-43*.—Press the button on the front end of the magneto (fig. 1) and hold until the engine stops.

(b) *PE-HB-43*.—Press the switch which is located in the flywheel housing near the muffler (fig. 3) and hold until the engine stops.

(c) *PE-HC-43, PE-HD-43, PE-HE-43*.—Press the switch which is mounted on the spark plug shield (fig. 5) and hold until engine stops.

*b. Charging the batteries*.—After the power unit and panel are connected by the cord as described in paragraph 4c, proceed as follows:

(1) Open the switches (or trip the circuit-breakers, if used) marked "BAT 1," "BAT 2," and "BAT 3" (figs. 7 and 12).

(2) Inspect all batteries in each bank to see that they are properly connected to each other.

(3) Connect the positive and negative leads from each bank of batteries to the respective + and — binding posts on the switch or switches selected. A circuit diagram of battery connections is shown in figure 16.

(4) Start the power unit.

(5) Turn all rheostat handles completely to the right.

(6) Close the battery switches or circuit breakers in use.

(7) Note the voltmeter and ammeter readings.

(8) Increase or decrease the charging current or currents to the proper rate by adjusting the rheostat or rheostats in series with the ammeters in use. Do not charge batteries at a rate exceeding 7½ amperes.

(9) Never charge more than six nor less than two batteries BB-29 or their equivalent on any one charging circuit.

**6. Removal from service.**—*a. Repacking for transportation in field*.—To repack the set for transportation after it has been in operation in the field, proceed as follows: Open the switches (or trip the circuit-breakers, if used) marked "BAT 1," "BAT 2," and "BAT 3"; remove the leads from the banks of batteries; remove the connecting cord from the power unit and neatly roll it to fit inside the panel case; close the panel case; place the top of the packing crate over the power unit and fasten it by means of the four trunk bolts (fig. 17).

*b. Preparation for storage*.—Before placing the charging set in storage, check all parts for serviceability and repair or replace parts if necessary. Cover all metal tools and spare parts with cosmoline and cover all unpainted metal parts of the power unit with a light oil. Drain all gasoline and oil from the power unit. Take care that no oil gets on the electrical wiring. Check with the list of parts in paragraph 11 to see that no parts of the set are missing or are in excess.




FIGURE 16.—Charging set SCR-169—circuit diagram with batteries.

TL-3250

**7. Function of parts.**—*a. Power unit PE-( )-43.*—(1) *Power unit PE-HA-43.*—(a) *Speed regulation.*—The automatic electric voltage regulator operates to control the fuel feed so as to maintain an engine speed between 1,500 and 1,600 rpm (fig. 1).

(b) *Voltage regulation.*—The voltage regulator is designed to maintain the output voltage of the generator between 32 and 40 volts




FIGURE 17.—Shipping crate for power unit PE-( )-43.

under load. It is adjusted at the factory to maintain 32 volts under full load when the armature is turning between 1,500 and 1,600 rpm. For further adjustment, if necessary, see paragraph 10i(1)(a) and j(1)(a).

(2) *Power unit PE-HB-43—voltage regulation.*—The voltage delivered by this power unit depends upon the speed. The speed is controlled by the governor spring tension. The adjustment for the

governor is a knurled and slotted screw with a lock nut and is located below and to the left of the carburetor (fig. 2). To raise the voltage, loosen the lock nut and turn the adjusting screw clockwise. To lower the voltage, turn the adjusting screw counterclockwise. Do not set for more than 40 volts at normal load. Always be sure to tighten the lock nut when the desired voltage is obtained.

(3) *Power units PE-HC-43, PE-HD-43, and PE-HE-43 voltage regulation.*—The voltage delivered by these power units depends upon the speed of the engine, which is controlled by the governor spring tension. The governor has been tested and set for an operating speed of 2,350 rpm with the generator delivering full load. This adjustment should not be disturbed unless further adjustment is necessary. In this case turn the knurled nut on the governor adjusting screw clockwise to increase speed, or counterclockwise to reduce speed (fig. 5).

b. *Panel BD-( )-61.*—(1) *Panel BD-LL-61.*—(a) The function of the panel is to control and indicate the rate of charge to storage batteries; its circuit diagram is shown in figure 10. Provision is made for charging 1, 2, or 3 banks of batteries separately or simultaneously. An individual rheostat and an ammeter are provided for each of the three charging circuits.

(b) A magnetic contactor switch having three separately insulated and independent poles actuated by a single magnet is controlled by the automatic switch.

(c) The automatic switch controls the energizing circuit of the magnetic contactor switch in the following manner: The former closes the latter when the generator voltage reaches 40 volts; and opens it when the generator voltage falls below 32 volts, when the generator voltage fails, or when the current is reversed and flows from any one of the banks of batteries into the generator (fig. 16).

(2) *Panels BD-LM-61, BD-LN-61, BD-LO-61, and BD-LP-61.*—These panels perform the same functions as panel BD-LL-61 and are similar in design and appearance, except—

(a) Dimensions vary somewhat.

(b) Inclosed circuit-breakers are used instead of open switches and fuses.

(c) The magnetic contactor switch is inclosed.

A circuit diagram of these panels is shown in figure 11.

**8. Care of set.**—All parts of the set should be carefully handled. When installed, and at regular intervals thereafter, the set should be cleaned in order to keep it free from dirt and foreign substances. A daily inspection of all parts of the set should be made as a matter of routine in order to insure its best operating condition. This inspec-

tion should include an examination for worn, broken, or corroded connections or parts; dirty panel; and grease and oil on engine or generator of the power unit.

**9. Maintenance and repair of power unit PE-( )-43.**—The inspection outlined in paragraph 4c and the correction of any defects noted are generally all the maintenance required. However, the following instructions on the servicing of the power unit should be carefully observed in the maintenance of the unit:

*a. Engine.*—(1) *PE-HA-43.*—(a) *Lubrication.*—Only the oils issued for the purpose should be used in lubricating the engine. One-




FIGURE 18.—Power unit PE-HA-43—use of carbon scraper.

half pint of good quality oil of viscosity SAE 40 should be mixed with each gallon of gasoline used as fuel. This provides automatic lubrication to all engine parts.

(b) *Removing carbon.*—To remove carbon from the engine remove the muffler and spark plug. Using the tool provided with the unit, carefully scrape the carbon deposits from the piston head, cylinder head, exhaust port, and spark-plug hole (fig. 18). The scraper should not come in contact with the cylinder wall. The cylinder should not be removed.

(c) *Care of magneto.*—Examine the contact breaker points at least



once every 100 hours of operation, and clean and dress them if necessary. Use No. 00 grade sandpaper for dressing the points. Do not use emery cloth.

(d) *Carburetor adjustment.*—The carburetor is properly attached and adjusted to the engine before leaving the factory. Readjustment is necessary to compensate for climatic changes and for changes in the load. If, when attempting to start the engine for the first time, it does not run perfectly, first check the ignition. If the ignition circuits and adjustments are correct, proceed as follows:

1. *Starting.*—Push the choke plunger in as far as possible after inserting a few drops of gasoline into the choke body (fig. 1). Then turn the carburetor adjustment at the bottom of the carburetor in a clockwise direction until it is tight and then back in a counterclockwise direction one turn. If the engine still fails to start, vary the carburetor adjustment by quarter turns until a point is found where the engine will operate.
2. *Adjustment for operation.*—After the engine has been run under load for a sufficient length of time to have developed normal operating temperature, adjust the carburetor until the engine runs smoothly.

(2) *PE-HB-43.*—(a) *Lubrication.*—For proper lubrication, an adequate supply of a high grade, well-refined oil in the crankcase is essential. A viscosity of SAE 20 is suitable for average duty requirements, which consist of intermittent full loading or sustained partial loads. In hot weather, when heavy duty is required, that is, full loading for long periods of time, the use of oil of viscosity SAE 30 is advisable. Never use heavier than SAE 20 in cold weather.

1. Check the level of the oil in the crankcase every time the fuel supply is replenished. Add sufficient oil to bring the level of the oil to the top of the filler fitting.
2. After every 100 hours of operation the crankcase should be completely drained and refilled with fresh oil. (See (3)(a)2 below.)
3. Whenever the drained oil shows signs of becoming thick or sticky, the crankcase should be removed and cleaned. (See (3)(a)3 and 4 below.)
4. After every 50 hours of operation, the generator end bearing should be lubricated. A hole is provided for the purpose in the end of the starting pulley. Do not use excessive oil; a few drops are sufficient.

(b) *Carburetor adjustment.*

1. The carburetor has only one adjustment, the needle valve for fuel regulation. Adjust for smooth operation when the engine is warmed up and under load. Avoid an over-rich mixture.
2. The air cleaner is to protect the engine from dust and dirt and should be cleaned occasionally by removing and washing in kerosene. Test to see if it is clogged by blowing through it or by noting if engine performs better with it off. If clogged it should be replaced.

(c) *Governor adjustment.*—The governor is located on the side of the engine below and to the left of the carburetor. If necessary to adjust, see paragraph 7a(2).

(d) *Magneto.*—To get at the breaker points, remove the flywheel housing cover and then the flywheel cover which is held in place by three small screws. Turn the flywheel until the breaker points are exposed to view between the flywheel spokes.

1. If points are worn or pitted, they should be dressed with No. 00 or finer sandpaper until both faces are clean and smooth. This is done best by inserting a piece of sandpaper, folded double with sand sides out, between the points and dressing both points at the same time, while holding the points together. This insures the points coming together squarely. Wipe or blow out all particles of sand after dressing.
  2. To adjust the breaker points, turn the flywheel until the cam on the crankshaft causes the breaker points to open to their fullest extent. Loosen the lock nut on the stationary point and insert a feeler gage or some other strip of metal 0.010 inch thick between the breaker points. Holding the points together with the feeler gage between them, tighten the adjusting screw which carries one point, and lock it in position with the lock nut. The maximum space between the points should equal the thickness of the feeler gage, or 0.010 inch. Check this space carefully. A slight further adjustment may be necessary.
- (3) *PE-HC-43, PE-HD-43, PE-HE-43.*—(a) *Lubrication.*—The most important point in the care of the gasoline engine is an adequate

supply of oil in the crankcase. A good quality oil with a viscosity of SAE 20 should be used for all year operation.

1. Check the oil in the base every time the fuel tank is filled. Add sufficient oil to bring the level of the oil to the top of the filler fitting.
2. After every 100 hours of operation the crankcase should be completely drained and refilled with fresh oil. Dilution of the oil by unburned fuel that may pass the piston rings and the gradual accumulation of dirt and small particles of metal in the crankcase make this a very necessary operation. The oil should be drained just after the engine has been run and while it is still hot. Always allow the crankcase to drain completely and do not use flushing solvents such as kerosene. Before refilling with the correct grade of fresh oil, make sure that the drain plug has been tightened securely.
3. Certain pockets in the crankcase will gradually accumulate a sediment that is the result of wear, carbon flaking, and dirt. In cold weather, water will collect in the crankcase when the moisture in the gasoline condenses as it passes the piston rings. This mixture of dirt, oil, water, and carbon, which is known as sludge, forms a gummy emulsion that will clog the oil strainer and pump valves and cause serious trouble if not removed in time. The condition of the drained oil should be carefully observed and whenever it shows signs of becoming sticky or thick, the crankcase should be thoroughly cleaned.
4. To clean the crankcase, remove the four screws that hold the crankcase to the base and clean out the sludge. Wash the oil pump at this time with a good grade of brush and naphtha. Do not use waste in cleaning the engine; if cloth must be used, it should be free of lint, as cheesecloth. If the gasket between the base and crankcase has been damaged in any way, replace it with a new gasket. Be sure to fill crankcase with clean oil to the top of the filler plug before starting engine.

(b) *Carburetor adjustment.*—The carburetor is an especially designed adjustable float-feed type. Adjustments should be made only when the engine is under load. Too rich a mixture should be avoided.

1. The sediment chamber should be cleaned whenever necessary. Close the shut-off valve in the line from the fuel

tank and loosen the knurled thumbscrew at the bottom of the glass receptacle. When replacing the chamber, make sure that the rim of the glass is clean and firmly seated against the gasket. Replace gasket if it is damaged.

2. The air cleaner is to protect the engine from dust and dirt and should be cleaned occasionally by removing and washing in kerosene. Test to see if it is clogged by blowing through it or by noting if the engine performs better with it off. If clogged it should be replaced. Keep the oil level in air cleaner up to the beading on the body.

(c) *Governor adjustment.*—The governor has been adjusted for an operating speed of 2,350 rpm and should not be disturbed unless further adjustment is necessary. If necessary to adjust, refer to paragraph 7a(3).

(d) *Magneto.*—While the magneto plate is on the engine, turn the crankshaft by hand to see if contact points open and close properly. Points must be clean and line up squarely to make a good electrical contact. Do not use a file or emery cloth for dressing contact points. No. 00 grade sandpaper or finer should be used for best results.

b. *Generator.*—(1) *PE-HA-43.*—(a) *Lubrication.*—After every 50 hours of operation place a few drops of oil in the oilhole in the starting pulley. The generator ball bearings at the engine end of the shaft are automatically lubricated if fuel directions are followed.

(b) *Cleaning.*—Clean the carbon dust from the commutators and brush holders after every 100 hours of operation. If wiping with a coarse cloth does not clean the commutator sufficiently, rub lightly and sparingly with No. 00 or finer sandpaper while the unit is running.

(c) *Brushes.*—Replace immediately any broken or worn-out brushes. Keep an extra set of brushes available at all times. Replace brushes as follows: Remove the generator cover; loosen the nuts between the starting pulley and the housing; turn the bakelite insulating disk and the brush ring and remove the brushes; install new brushes; align the white lines on the housing, the bakelite insulation disk, and the brush ring; tighten the nuts and replace the generator cover. Improper alignment of the white lines will cause excessive arcing and loss of power.

(d) *Voltage regulator.*—The voltage regulator is of commercial design. The adjustment screw is located on top of the regulator. Turning the screw in a clockwise direction increases the voltage. Turning the screw in a counterclockwise direction decreases the voltage. Tighten the lock nut after adjustment.

(2) *PE-HB-43.*—(a) *Lubrication.*—Too much oil in the generator bearing may cause trouble, as the excess oil may get on the commu-

tator. The bearing has a reservoir and a substantial oil wick to carry oil to the shaft. A few drops of oil in the oil cup every 100 hours of operation will prove adequate.

(b) *Cleaning*.—Inspect commutator through inspection plate at bottom of end bell every 100 hours of operation. If dirty, wipe with coarse cloth; if this does not clean commutator sufficiently, rub lightly with No. 00 grade sandpaper or finer while unit is running.

(c) *Brushes*.—To remove brushes, remove slotted composition caps at sides of generator end bell and pull out brush. Brushes are marked R (right, facing generator) and L (left). Replace in same order and manner, letters up. Replace any broken or worn-out brushes. Keep an extra set of brushes available at all times.

(3) *PE-HC-43, PE-HD-43, PE-HE-43*.—(a) *Lubrication*.—Since there are no bearings in the generator, no lubrication is required.

(b) *Cleaning*.—Inspect commutator by removing the end cover which is fastened to the generator frame by three machine screws.

To clean the commutator, wipe with a coarse cloth; if this does not clean sufficiently, rub lightly with No. 00 or finer sandpaper while the unit is running.

(c) *Brushes*.—To remove brushes, remove lock wires holding brush and spring in brush holder. Remove the machine screw holding brush pigtail terminal to brush holder. Replace immediately any broken or worn-out brushes. Keep an extra set of brushes available at all times.

**10. Troubles and their remedies.**—Following are listed the most common troubles that may develop in the power unit PE-( )-43, and their remedies:

| <i>Trouble</i>                                                | <i>Remedy</i>                                                                                                                                 |
|---------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| <i>a. Engine difficult to start, or stops after starting.</i> |                                                                                                                                               |
| (1) Fuel supply exhausted.                                    | (1) Fill tank with proper fuel mixture.                                                                                                       |
| (2) Gasoline flow obstructed.                                 | (2) Clean out fuel line.                                                                                                                      |
| (3) Cylinder flooded.                                         | (3) Open choke, turn engine over a few times, and let stand a few minutes before starting.                                                    |
| (4) Improper gas mixture.                                     | (4) Adjust carburetor.<br>(a) PE-HA-43 (par. 9a(1)(d)).<br>(b) PE-HB-43 (par. 9a(2)(b)).<br>(c) PE-HC-43, PE-HD-43, PE-HE-43 (par. 9a(3)(b)). |
| (5) Defective magneto.                                        | (5)                                                                                                                                           |
| (a) Breaker points worn or pitted.                            | (a) Clean and smooth points (par. 9).                                                                                                         |

| <i>Trouble</i>                                                                                                                                                                                                                                              | <i>Remedy</i>                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| (b) Breaker points out of adjustment.                                                                                                                                                                                                                       | (b) Adjust points to proper clearance (par. 9).                                                                                                             |
| (c) Breaker cam out of time (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43).                                                                                                                                                                                       | (c) Check flywheel shaft key.                                                                                                                               |
| (d) Switch wire loose or defective.                                                                                                                                                                                                                         | (d) Repair or replace switch wiring or insulation.                                                                                                          |
| (e) High-voltage wire loose or defective (PE-HA-43).                                                                                                                                                                                                        | (e) Repair or replace high-voltage wiring.                                                                                                                  |
| (6) Voltage regulator stuck (PE-HA-43).                                                                                                                                                                                                                     | (6) Tap outside of case lightly or remove plunger and clean.                                                                                                |
| <p>NOTE.—Care should be exercised to prevent damage of plunger or sleeve while cleaning or reassembling unit. The long holding screw through the shell assembly and shell end should extend into but not through the opening provided in plunger shell.</p> |                                                                                                                                                             |
| (7) Throttle valve stuck or out of adjustment (PE-HC-43, PE-HD-43, PE-HE-43).                                                                                                                                                                               | (7) Clean and oil or readjust valve.                                                                                                                        |
| (8) Throttle rod loose (PE-HC-43, PE-HD-43, PE-HE-43).                                                                                                                                                                                                      | (8) Tighten setscrew.                                                                                                                                       |
| (9) Valve seats bad (PE-HC-43, PE-HD-43, PE-HE-43).                                                                                                                                                                                                         | (9) Reseat valves (see TM 11-360).                                                                                                                          |
| (10) Valve sticking (PE-HC-43, PE-HD-43, PE-HE-43).                                                                                                                                                                                                         | (10) Clean valves (see TM 11-360).                                                                                                                          |
| (11) Water in fuel supply.                                                                                                                                                                                                                                  | (11) Drain carburetor (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43), and refill with fuel from tank. If water is still present, drain tank and refill with fuel. |
| (12) Spark plug fouled or cracked.                                                                                                                                                                                                                          | (12) Clean or replace plug.                                                                                                                                 |
| (13) Intake manifold leaking.                                                                                                                                                                                                                               | (13) Replace gasket or manifold if necessary.                                                                                                               |
| (14) Improper timing.                                                                                                                                                                                                                                       | (14) (a) PE-HB-43.—When the piston comes up on exhaust stroke                                                                                               |

*Trouble**Remedy*

the exhaust valve should be closed when the piston reaches top dead center. The next stroke is the intake stroke, and the intake valve should start to open after the crank has traveled from 4° to 5° past dead center, or the piston has traveled down from top dead center a distance of from 0.009 to 0.010 inch.

(b) *PE-HC-43, PE-HD-43, PE-HE-43*.—To check valve clearance, remove valve cover plate. The correct clearance of the exhaust valve is 0.008 inch and the intake valve 0.006 inch when the engine is cold. Tappet clearance is adjusted by grinding the required amount from the end of the valve stem. End of the stem must be square with stem proper. The valves are timed by the meshing of the camshaft gear with the gear on the crankshaft. These gears are properly meshed when the mark on the camshaft gear is in line with the mark on the crankshaft collar. To reseal valves grind in the same manner as automobile valves.

(15) Loose or defective wiring.

(15) Tighten, repair, or replace wiring.

*b. Engine misses or stops suddenly.*

(1) Fuel supply exhausted or fuel line clogged.

(1) Fill tank or blow out fuel line.

(2) Loose, broken, or fouled spark plug.

(2) Tighten, clean, or replace plug.

(3) Fouled magneto points.

(3) Clean or replace points (par. 9).

(4) Defective wiring.

(4) Replace wiring.

(5) Valves warped or sticking (*PE-HB-43, PE-HC-43, TM 11-360, PE-HD-43, PE-HE-43*).

(5) Clean or replace valves (see



| <i>Trouble</i>                                                                            | <i>Remedy</i>                                                                                                                            |
|-------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| (6) Valve tappets sticking or out of adjustment (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43). | (6) See (8) below and TM 11-360.                                                                                                         |
| (7) Carburetor out of adjustment.                                                         | (7) Adjust carburetor (a(4) above).                                                                                                      |
| (8) Cylinder head gasket leaking (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43).                | (8) Replace gasket.                                                                                                                      |
| (9) Manifold gasket leaking.                                                              | (9) Replace gasket.                                                                                                                      |
| <i>c. Engine overheating.</i>                                                             |                                                                                                                                          |
| (1) Poor grade of oil or insufficient oil.                                                | (1) Use only specified oil in specified quantity (par. 5).                                                                               |
| (2) Excessive carbon deposit.                                                             | (2) Remove carbon.                                                                                                                       |
| (3) Magneto points out of adjustment.                                                     | (3) Adjust points (par. 9).                                                                                                              |
| (4) Carburetor out of adjustment.                                                         | (4) Adjust carburetor (par. 9).                                                                                                          |
| (5) Choke partly closed.                                                                  | (5) Open choke.                                                                                                                          |
| (6) Piston rings sticking.                                                                | (6) Use proper grade of oil. If still sticking, replace rings.                                                                           |
| (7) Improper timing (PE-HC-43, PE-HD-43, PE-HE-43).                                       | (7) Correct timing (a(14) above).                                                                                                        |
| (8) Muffler clogged.                                                                      | (8) Clean or replace muffler.                                                                                                            |
| (9) Governor or thistle loose.                                                            | (9) Tighten setscrews and lock nuts.                                                                                                     |
| (10) Air cleaner clogged.                                                                 | (10) Remove and wash in kerosene.                                                                                                        |
| (11) Excessive oil in fuel (PE-HA-43).                                                    | (11) Use only specified amount of oil (par. 5a(1)(a)).                                                                                   |
| <i>d. Engine knocks.</i>                                                                  |                                                                                                                                          |
| (1) Improper fuel mixture.                                                                | (1) Allow engine to reach normal operating temperature under load, open choke, and adjust carburetor (par. 9).                           |
| (2) Heavy carbon deposit in cylinder.                                                     | (2) Remove carbon.<br>(a) PE-HA-43.—See paragraph 9a(1)(b).<br>(b) PE-HC-43, PE-HD-43, PE-HE-43.—Remove cylinder head and remove carbon. |

| <i>Trouble</i>                                                    | <i>Remedy</i>                                                                                         |
|-------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|
| (3) Overheated engine.                                            | (3) See <i>c</i> above.                                                                               |
| (4) Magneto points set too far apart.                             | (4) Set points to proper clearance (par. 9).                                                          |
| (5) Loose main bearings or connecting rod bearings.               | (5) Replace loose bearings.                                                                           |
| (6) Loose flywheel.                                               | (6) Replace key and tighten flywheel.                                                                 |
| (7) Lack of oil (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43).         | (7) Add sufficient amount of proper grade of oil to bring level up to top of filler fitting (par. 5). |
| (8) Loose valve tappets (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43). | (8) Set tappets to proper clearance.                                                                  |

(a) *Exhaust*.—.008 inch with engine cold.

(b) *Intake*.—.006 inch with engine cold.

Clearance is adjusted by grinding the required amount off the end of the valve stem, keeping end square with stem proper.

*e. Engine lacks power.*

|                                                                           |                                                       |
|---------------------------------------------------------------------------|-------------------------------------------------------|
| (1) Engine overheated due to excessive carbon.                            | (1) Remove carbon ( <i>d</i> (2) above).              |
| (2) Carburetor out of adjustment.                                         | (2) Adjust carburetor (par. 9).                       |
| (3) Magneto points too close.                                             | (3) Adjust points (par. 9).                           |
| (4) Poor compression.                                                     | (4)                                                   |
| (a) Valves not seating (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43).          | (a) Grind valves in same manner as automobile valves. |
| (b) Valves sticking (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43).             | (b) See TM 11-360.                                    |
| (c) Valves tappets sticking (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43).     | (c) Clean in same manner as ( <i>b</i> ) above.       |
| (d) Valve tappets set too close (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43). | (d) Set to proper clearance ( <i>d</i> (8) above).    |
| (e) Piston ring defective.                                                | (e) Replace piston ring.                              |
| (f) Loose, fouled, or cracked spark plug.                                 | (f) Tighten, clean, or replace plug.                  |

| <i>Trouble</i>                                                   | <i>Remedy</i>                                                                                                                                                                                                                |
|------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| (5) Poor fuel.                                                   | (5) Replace with suitable fuel.                                                                                                                                                                                              |
| (6) Voltage regulator inoperative (PE-HA-43).                    | (6) Check leads that connect regulator to the output of the generator, If the regulator becomes unserviceable, remove it and its leads, plug the hole in the top of the carburetor with a cork, and continue to use the set. |
| (7) Muffler clogged by carbon.                                   | (7) Clean muffler.                                                                                                                                                                                                           |
| (8) Governor loose.                                              | (8) Tighten governor lock nut or setscrew (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43).                                                                                                                                          |
| (9) Improper timing.                                             | (9) Correct timing ( <i>a</i> (14) above).                                                                                                                                                                                   |
| (10) Oil badly diluted (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43). | (10) Change oil.                                                                                                                                                                                                             |
| (11) Air cleaner clogged.                                        | (11) Remove and wash in kerosene. If still clogged, replace.                                                                                                                                                                 |

*f. Explosion in carburetor or in intake manifold.*

|                                                                                        |                                 |
|----------------------------------------------------------------------------------------|---------------------------------|
| (1) Fuel mixture too lean.                                                             | (1) Open needle valve slightly. |
| (2) Intake valve sticking, warped, or broken (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43). | (2) Clean or replace valve.     |
| (3) Intake valve spring weak.                                                          | (3) Replace valve spring.       |
| (4) Intake tappets set too close (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43).             | (4) See <i>d</i> (8) above.     |
| (5) Intake manifold leaking.                                                           | (5) Replace gasket or manifold. |
| (6) Cylinder head gasket leaking.                                                      | (6) Replace gasket.             |

*g. Excessive smoke from exhaust.*

|                                                            |                                                         |
|------------------------------------------------------------|---------------------------------------------------------|
| (1) Too much oil.                                          | (1)                                                     |
| (a) In fuel (PE-HA-43).                                    | (a) Use only specified quantity of proper grade of oil. |
| (b) In crankcase (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43). | (b) Use specified quantity of proper grade of oil.      |
| (2) Carburetor needle valve open too far.                  | (2) Partly closed needle valve.                         |

| <i>Trouble</i>                                                                     | <i>Remedy</i>                                                                                                                              |
|------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| (3) Carburetor float sticking or leaking (PE-HB-43, PE-HC-43, PE-HD-43, PE-HE-43). | (3) Clean or replace float.                                                                                                                |
| (4) Worn piston or rings.                                                          | (4) Replace piston or rings.                                                                                                               |
| <i>h. Generator gives no voltage.</i>                                              |                                                                                                                                            |
| (1) Open windings.                                                                 | (1) Do not attempt to make repairs in the using organization.                                                                              |
| (2) Broken brush leads or poor brush contact.                                      | (2) Examine and repair or replace broken connections, or replace brushes as indicated in paragraph 9b(1)(c), (2)(c), or (3)(c).            |
| <i>i. Generator voltage too high.</i>                                              |                                                                                                                                            |
| Engine speed too fast.                                                             | Decrease engine speed.                                                                                                                     |
| (1) PE-HA-43.                                                                      | (1) Turn adjusting screw on top of the voltage regulator in a counter-clockwise direction until the proper voltage is obtained under load. |
| (2) PE-HB-43.                                                                      | (2) See paragraph 9a(2)(c).                                                                                                                |
| (3) PE-HC-43, PE-HD-43, PE-PE-HE-43.                                               | (3) See paragraph 9a(3)(c).                                                                                                                |
| <i>j. Generator voltage too low.</i>                                               |                                                                                                                                            |
| (1) Engine speed too slow.                                                         | (1) Increase engine speed.                                                                                                                 |
| (a) PE-HA-43.                                                                      | (a) Turn adjusting screw on top of voltage regulator in a clockwise direction until proper voltage is obtained under load.                 |
| (b) PE-HB-43.                                                                      | (b) See paragraph 9a(2)(c).                                                                                                                |
| (c) PE-HC-43, PE-HD-43, PE-HE-43.                                                  | (c) See paragraph 9a(3)(c).                                                                                                                |
| (2) Poor brush contact.                                                            | (2) Replace brushes.                                                                                                                       |
| (a) PE-HA-43.                                                                      | (a) See paragraph 9b(1)(c).                                                                                                                |
| (b) PE-HB-43.                                                                      | (b) See paragraph 9b(2)(c).                                                                                                                |
| (c) PE-HC-43, PE-HD-43, PE-HE-43.                                                  | (c) See paragraph 9b(3)(c).                                                                                                                |

**11. List of replacement parts.**—A list of replacement parts of power unit PE-( )-43 and panel BD-( )-61 is given below (*a* to *au*, incl.). Some parts of power units PE-HD-43 and PE-HE-43 are not included in this list since complete data are not available.

| A                  | B                                                                   | C                                         | D                                               | E                                      | F                                             | G                                          |
|--------------------|---------------------------------------------------------------------|-------------------------------------------|-------------------------------------------------|----------------------------------------|-----------------------------------------------|--------------------------------------------|
| Item reference No. | Name of item                                                        | PE-HA-43                                  | PE-HB-43                                        | PE-HC-43                               | PE-HD-43                                      | PE-HE-43                                   |
|                    |                                                                     | Homelite Corporation, Port Chester, N. Y. | United States Motors Corporation, Oshkosh, Wis. |                                        | Climax Engineering Corporation, Clinton, Iowa |                                            |
| a                  | Connecting rod and piston assembly<br>Includes items                |                                           | RA-2005<br>1 to 12                              |                                        |                                               |                                            |
| b                  | Connecting rod assembly<br>Includes items                           | 11034<br>7                                | RA-1025<br>7 to 12                              | 99790<br>8 to 10<br>29386<br>1 to 4; 6 | 99790<br>8 to 12<br>99920<br>1 to 4; 6        | 99790.<br>8 to 12.<br>99920.<br>1 to 4; 6. |
| c                  | Piston assembly, standard<br>Includes items                         |                                           |                                                 |                                        |                                               |                                            |
| 1                  | Piston, standard                                                    | 11569                                     | RA-5                                            | 99917                                  | 99963                                         | 99963.                                     |
| 2                  | Ring, piston compression, standard                                  | 10534                                     | RA-14                                           | 65451                                  | 21203                                         | 21203.                                     |
| 3                  | Ring, piston center, standard                                       |                                           | RA-111                                          | 65451                                  | 21202                                         | 21202.                                     |
| 4                  | Ring, piston oil retaining, standard                                |                                           | RA-484                                          | 61505                                  | 61505                                         | 61505.                                     |
| 5                  | Pin, piston, standard                                               | 10546                                     | RA-27                                           | 65863                                  | 65863                                         | 65863.                                     |
| 6                  | Ring, piston pin retaining                                          | 10547                                     | RA-23                                           | 66246                                  | 66246                                         | 66246.                                     |
| 7                  | Bushing, piston pin                                                 | 10542                                     | RA-48                                           |                                        |                                               |                                            |
| 8                  | Screw, connecting rod                                               |                                           | RA-89                                           | 63689                                  | 92146                                         | 92146.                                     |
| 9                  | Nut, connecting rod screw                                           |                                           | 5-M                                             | 91643                                  |                                               |                                            |
| 10                 | Cotter pin, connecting rod screw                                    |                                           | 4-P-06                                          | 92288                                  |                                               |                                            |
| 11                 | Rod, connecting                                                     |                                           | RA-25-A                                         |                                        |                                               |                                            |
| 12                 | Washer, connecting rod screw                                        |                                           | RA-04                                           |                                        | 22082                                         | 22082.                                     |
| 13                 | Crank-pin bearing assembly                                          | 11710                                     |                                                 |                                        |                                               |                                            |
| 14                 | Screw, crank pin                                                    | 11078                                     |                                                 |                                        |                                               |                                            |
| 15                 | Lock washer, crank pin screw                                        | 10525                                     |                                                 |                                        |                                               |                                            |
| 16                 | Washer, crank pin outer                                             | 11252                                     |                                                 |                                        |                                               |                                            |
| 17                 | Washer, crank pin inner                                             | 11079                                     |                                                 |                                        |                                               |                                            |
| d                  | Piston assembly, 0.010 inch oversize <sup>1</sup><br>Includes items |                                           |                                                 | 99967<br>18 to 21                      | 99967<br>18 to 21                             | 99967.<br>18 to 21.                        |
| e                  | Piston assembly, 0.020 inch oversize <sup>1</sup><br>Includes items |                                           |                                                 | 99968<br>22 to 25                      | 99968<br>22 to 25                             | 99968.<br>22 to 25.                        |
| f                  | Piston assembly, 0.030 inch oversize <sup>1</sup><br>Includes items |                                           |                                                 | 99969<br>26 to 29                      | 99969<br>26 to 29                             | 99969.<br>26 to 29.                        |
| 18                 | Piston, 0.010 inch oversize <sup>1</sup>                            |                                           |                                                 | 99964                                  | 99964                                         | 99964.                                     |

|    |                                                             |           |          |          |
|----|-------------------------------------------------------------|-----------|----------|----------|
| 19 | Ring, piston compression, 0.010 inch oversize <sup>1</sup>  | 61010     | 21219    | 21219    |
| 20 | Ring, piston center, 0.010 inch oversize <sup>1</sup>       | 61010     | 21222    | 21222    |
| 21 | Ring, piston oil retainer, 0.010 inch oversize <sup>1</sup> | 61747     | 61747    | 61747    |
| 22 | Piston, 0.020 inch oversize <sup>1</sup>                    | 99965     | 99965    | 99965    |
| 23 | Ring, piston compression, 0.020 inch oversize <sup>1</sup>  | 61012     | 21220    | 21220    |
| 24 | Ring, piston center, 0.020 inch oversize <sup>1</sup>       | 61012     | 21223    | 21223    |
| 25 | Ring, piston oil retainer, 0.020 inch oversize <sup>1</sup> | 61748     | 61748    | 61748    |
| 26 | Piston, 0.030 inch oversize <sup>1</sup>                    | 99966     | 99966    | 99966    |
| 27 | Ring, piston compression, 0.030 inch oversize <sup>1</sup>  | 61013     | 21221    | 21221    |
| 28 | Ring, piston center, 0.030 inch oversize <sup>1</sup>       | 61013     | 21224    | 21224    |
| 29 | Ring, piston oil retainer, 0.030 inch oversize <sup>1</sup> | 61749     | 61749    | 61749    |
| 30 | Pin, piston, 0.005 inch oversize <sup>1</sup>               | 63436     | 63436    | 63436    |
| ø  | Crankshaft assembly                                         | RA-1024-5 |          |          |
|    | Includes items                                              | 31 to 35  |          |          |
| 31 | Crankshaft                                                  | RA-24-T   | 26377    | 26377    |
| 32 | Gear, timing on crankshaft                                  | RA-12     |          |          |
| 33 | Collar, spacing on crankshaft                               | RA-40     |          |          |
| 34 | Pin, timing gear                                            | RA-103    |          |          |
| 35 | Cone, bearing, on crankshaft                                | RA-428    |          |          |
| 36 | Key, flywheel                                               | 66403     | 66403    | 66403    |
| 37 | Key, generator coupling                                     | 63159     |          |          |
| 38 | Nut, crank throw                                            | 10526     |          |          |
| 39 | Lock washer, crank throw nut                                | 10525     |          |          |
| h  | Oil pump assembly                                           |           |          |          |
|    | Includes items                                              | RA-1193   | 29569    | 29569    |
| i  | Piston assembly, oil pump                                   | 40 to 52  | 43 to 46 | 43 to 46 |
|    | Includes items                                              | RA-1366   |          |          |
| 40 | Piston, oil pump                                            | 40 to 42  |          |          |
| 41 | Ball, oil pump check, ¼ inch                                | RA-366    | 63207    | 63207    |
| 42 | Pin, oil pump ball stop                                     | 8-AE      |          |          |
| 43 | Plunger, oil pump                                           | RA-367-A  |          |          |
| 44 | Body, oil pump                                              | RA-364-B  | 29340    | 29340    |
| 45 | Spring, oil pump, large                                     | 29338     | 29338    | 29338    |
| 46 | Spring, oil pump, small                                     | RA-375-B  |          |          |
| 47 | Retainer, oil pump check ball                               | RA-377    | 26413    | 26413    |
| 48 | Guide, oil pump plunger                                     | RA-388-A  |          |          |
| 49 | Body, oil strainer                                          | RA-426    |          |          |
| 50 | Screen, oil strainer                                        | RA-477    |          |          |
|    |                                                             | RA-478    | 69120    | 69120    |

<sup>1</sup> Denotes an oversize repair item which is not required except when replacing to compensate for wear in other parts.

| A                        | B                                              | O                                                        | D                                                              | E         | F         | G          |
|--------------------------|------------------------------------------------|----------------------------------------------------------|----------------------------------------------------------------|-----------|-----------|------------|
| Item<br>reference<br>No. | Name of item                                   | PE-HA-43<br>Homelite Corporation,<br>Port Chester, N. Y. | PE-HB-43<br>United States Motors Corporation,<br>Oshkosh, Wis. | PE-HC-43  | PE-HD-43  | PE-HE-43   |
| 51                       | Retainer, oil strainer screen.....             |                                                          | RA-480                                                         | 62082     | 62082     | 62082.     |
| 52                       | Ball, oil pump check, $\frac{5}{16}$ inch..... |                                                          | 10-A-E                                                         |           |           |            |
| 53                       | Screw, oil pump.....                           |                                                          | 5-C-06                                                         |           |           |            |
| 54                       | Lock washer, oil pump screw.....               |                                                          | 5-W                                                            |           |           |            |
| 55                       | Retainer, oil pump tube.....                   |                                                          |                                                                | 62081     | 62081     | 62081.     |
| 56                       | Rod, oil pump.....                             |                                                          |                                                                | 29011     | 29011     | 29011.     |
| 57                       | Tube, oil pump.....                            |                                                          |                                                                | 29065     | 29065     | 29065.     |
| 58                       | Connector, oil pump tube.....                  |                                                          |                                                                | 63202     | 63202     | 63202.     |
| j                        | Cylinder assembly.....                         |                                                          | RA-500103                                                      | 99216     | 89423     | 89423.     |
|                          | Includes items.....                            |                                                          | 59 to 78                                                       | 92, 93; L | 92, 93; L | 92, 93; L. |
| 59                       | Cylinder.....                                  | 11399                                                    | RA-1-F                                                         |           |           |            |
| 60                       | Valve, intake.....                             |                                                          | RA-20-A                                                        | 68923     | 68923     | 68923.     |
| 61                       | Valve, exhaust.....                            |                                                          | RA-20-A                                                        | 68273     | 23354     | 23354.     |
| 62                       | Cup, valve spring.....                         |                                                          | RA-72                                                          | 62233     | 62233     | 62233.     |
| 63                       | Spring, valve.....                             | 15080                                                    | RA-57-A                                                        | 65906     | 65906     | 65906.     |
| 64                       | Cap, valve spring retainer.....                |                                                          | RA-50                                                          | 68293     | 68293     | 68293.     |
| 65                       | Key, valve spring retainer.....                |                                                          | RA-258-A                                                       | 68283     | 68283     | 68283.     |
| 66                       | Guide, valve.....                              |                                                          | RA-197-A                                                       |           |           |            |
| 67                       | Tappets, valve (lifter).....                   |                                                          | RA-45-A                                                        | 62377     | 63277     | 63277.     |
| 68                       | Gear, cam.....                                 |                                                          | RA-26-A                                                        | 61167     | 61167     | 61167.     |
| 69                       | Cover, valve springs.....                      |                                                          | RA-19-A                                                        | 62154     | 62154     | 62154.     |
| 70                       | Gasket, valve spring cover.....                |                                                          | RA-217-A                                                       | 65617     | 65617     | 65617.     |
| 71                       | Screw, valve cover plate.....                  |                                                          | 5-C-05                                                         | 91389     | 91389     | 91389.     |
| 72                       | Washer, valve cover plate.....                 |                                                          | 5-W                                                            | 22353     | 22353     | 22353.     |
| 73                       | Plug, camshaft.....                            |                                                          |                                                                | 68122     | 68122     | 68122.     |
| 74                       | Shaft, cam gear.....                           |                                                          |                                                                | 68333     | 68333     | 68333.     |
| 75                       | Nut, cam gear stud.....                        |                                                          | 9-K                                                            |           |           |            |
| 76                       | Stud, main bearing housing.....                |                                                          | RA-61                                                          |           |           |            |
| 77                       | Lock washer, cam gear stud.....                |                                                          | 9-W                                                            |           |           |            |
| 78                       | Stud, cylinder head.....                       |                                                          | RA-68-A                                                        |           |           |            |
| 79                       | Shield, cylinder.....                          | 10555                                                    |                                                                | 62335     | 22142     | 22142.     |

41



| A                  | B                                      | C                                                        | D                                                              | E        | F        | G        |
|--------------------|----------------------------------------|----------------------------------------------------------|----------------------------------------------------------------|----------|----------|----------|
| Item reference No. | Name of item                           | PE-HA-43<br>Homelite Corporation,<br>Port Chester, N. Y. | PE-HB-43<br>United States Motors Corporation,<br>Oshkosh, Wis. | PE-HC-43 | PE-HD-43 | PE-HE-43 |
| 115                | Shield, spark plug                     |                                                          |                                                                | 20131    | 20131    | 20131.   |
| 116                | Spring, spark plug shield              |                                                          |                                                                | 46133    | 46133    | 46133.   |
| 117                | Nut, cylinder to base stud             |                                                          | 5-K                                                            |          |          |          |
| 118                | Lock washer, base stud nut             |                                                          | 5-W                                                            |          |          |          |
| 119                | Choke rod assembly                     |                                                          |                                                                | 99824    | 89431    | 89431.   |
| m                  | Governor assembly                      |                                                          | RA-1010                                                        |          |          |          |
|                    | Includes items                         |                                                          | 131 to 135                                                     |          |          |          |
| n                  | Governor housing assembly              |                                                          | RA-1053-2                                                      |          |          |          |
|                    | Includes items                         |                                                          | 120 to 130                                                     |          |          |          |
| o                  | Governor fork and lever shaft assembly |                                                          | RA-1054-2                                                      |          |          |          |
|                    | Includes items                         |                                                          | 124 to 130                                                     |          |          |          |
| p                  | Governor sleeve assembly               |                                                          | RA-1472                                                        |          |          |          |
|                    | Includes items                         |                                                          | 136, 137                                                       |          |          |          |
| 120                | Screw, speed regulator                 |                                                          | RA-44-B                                                        |          |          |          |
| 121                | Housing, governor fork                 |                                                          | RA-53-B                                                        |          |          |          |
| 122                | Spring, governor lever return          |                                                          | RA-58                                                          |          |          |          |
| 123                | Rod, throttle                          |                                                          | RA-490                                                         |          |          |          |
| 124                | Shaft, governor fork                   |                                                          | RA-52                                                          |          |          |          |
| 125                | Fork, governor                         |                                                          | RA-54-B                                                        |          |          |          |
| 126                | Lever, governor                        |                                                          | RA-55                                                          |          |          |          |
| 127                | Spring, governor                       |                                                          | RA-183                                                         |          |          |          |
| 128                | Screw, countersunk head                |                                                          | 8-32-AK-04                                                     |          |          |          |
| 129                | Pin, escutcheon                        |                                                          | 14-AN-04                                                       |          |          |          |
| 130                | Nut, check (plated)                    |                                                          | 7/16" SAE                                                      |          |          |          |
| 131                | Ball, governor                         |                                                          | RA-10-C                                                        |          |          |          |
| 132                | Head, governor                         |                                                          | RA-56                                                          |          |          |          |
| 133                | Stud, governor sleeve                  |                                                          | RA-473                                                         |          |          |          |
| 134                | Pin, governor ball                     |                                                          | RA-7-A                                                         |          |          |          |
| 135                | Stud, cam gear                         |                                                          | RA-28-A                                                        |          |          |          |
| 136                | Sleeve, governor                       |                                                          | RA-472-C                                                       |          |          |          |
| 137                | Bearing, ball                          |                                                          | RA-481                                                         |          |          |          |

|     |                                          |                |            |                 |                  |
|-----|------------------------------------------|----------------|------------|-----------------|------------------|
| 138 | Gasket, governor housing.....            | RA-294.....    |            |                 |                  |
| 139 | Screw, governor control.....             | 5-G-05.....    |            |                 |                  |
| 140 | Lock washer, governor control screw..... | 5-W.....       |            |                 |                  |
| 141 | Shaft, governor.....                     |                | 63493      | 63493           | 63439.           |
| 142 | Rushing, governor crank.....             |                | 63492      | 63492           | 63492            |
| 143 | Crank, governor.....                     |                | 68643      | 68643           | 68643.           |
| 144 | Gear, governor.....                      |                | 99543      | 29374           | 29374.           |
| 145 | Pin, cotter.....                         |                | 92288      | 92288           | 92288.           |
| 146 | Screw, governor lever clamp.....         |                | 90202      | 90202           | 90202.           |
| 147 | Spring, throttle.....                    |                | 67956      | 67956           | 67956.           |
| 148 | Link, throttle.....                      |                | 65126      | 26275           | 26275.           |
| 149 | Screw, governor gear.....                |                | 90891      | 90891           | 90891.           |
| 150 | Lock washer, governor gear screw.....    |                | 90832      | 90832           | 90832.           |
| 151 | Washer, governor gear screw.....         |                | 92305      | 92305           | 92305.           |
| 152 | Strap, governor control.....             |                | 22158      | 22158           | 22158.           |
| 153 | Control, governor.....                   |                | 89014      | 89014           | 89014.           |
| 154 | Bell crank assembly.....                 |                | 29208      | 29208           | 29208.           |
| 155 | Screw, bell crank.....                   |                | 91253      | 91253           | 91253.           |
| 156 | Rushing, bell crank.....                 |                | 63067      | 63067           | 63067.           |
| 157 | Washer, bell crank.....                  |                | 62199      | 62199           | 62199.           |
| 158 | Screw, bell crank.....                   |                | 90891      | 90891           | 90891.           |
| 159 | Clip, throttle spring.....               |                | 67992      |                 |                  |
| 160 | Screw, throttle spring clip.....         |                | 91196      |                 |                  |
| q   | Carburetor assembly.....                 | RAY-202-B..... | 96831      | 89430           | 89430.           |
| r   | Includes items.....                      |                | 161 to 187 | 161 to 275      | 161 to 275.      |
| s   | Carburetor cover assembly.....           |                | 29632      |                 |                  |
| t   | Includes items.....                      |                | 183 to 187 |                 |                  |
| u   | Choke wire assembly.....                 | RA-1350.....   |            |                 |                  |
| v   | Includes items.....                      | 263 to 267     |            |                 |                  |
| w   | Fuel filter assembly.....                |                | 99910      | 99910           | 99910.           |
| x   | Includes items.....                      |                | 268 to 275 | 268 to 275      | 268 to 275.      |
| y   | Air cleaner assembly.....                |                | 29447      | 99908           | 99908.           |
| z   | Includes items.....                      |                | 281 to 287 | 281 to 284; 286 | 281 to 284; 286. |
| 161 | Carburetor upper body assembly.....      |                | 99772      | 99772           | 99772.           |
| 162 | Includes items.....                      |                | 248 to 262 |                 | 248 to 262.      |
| 163 | Gasket, carburetor.....                  | RA-285.....    | 65667      | 68857           | 68857.           |
| 164 | Nozzle, carburetor.....                  | 05479          |            | 23351           | 23351.           |
| 165 | Valve, needle.....                       | 03941          | 69460      | 99621           | 99621.           |
| 166 | Nut, carburetor stuffing box.....        |                |            |                 |                  |
| 167 | Screen, carburetor.....                  | 0802           |            |                 |                  |

| A                             | B                                                           | O                                                            | D                                                                  | E        | F        | G        |
|-------------------------------|-------------------------------------------------------------|--------------------------------------------------------------|--------------------------------------------------------------------|----------|----------|----------|
| Item<br>refer-<br>ence<br>No. | Name of item                                                | PE-HA-43<br><br>Homelite Corporation,<br>Port Chester, N. Y. | PE-HB-43<br><br>United States Motors Corporation,<br>Oshkosh, Wis. | PE-HC-43 | PE-HD-43 | PE-HE-43 |
| 166                           | Bowl, carburetor.....                                       |                                                              |                                                                    | 99573    | 21395    | 21395.   |
| 167                           | Float, carburetor.....                                      |                                                              | 01459                                                              | 99149    | 99622    | 99622.   |
| 168                           | Hinge, pin, carburetor float.....                           |                                                              |                                                                    |          | 23114    | 23114.   |
| 169                           | Screw, carburetor cover.....                                |                                                              | 054                                                                | 90781    |          |          |
| 170                           | Lock washer, carburetor cover screw.....                    |                                                              | 0992                                                               | 90367    |          |          |
| 171                           | Barrel, carburetor.....                                     |                                                              |                                                                    | 99296    |          |          |
| 172                           | Horn air.....                                               |                                                              |                                                                    | 99825    |          |          |
| 173                           | Screw, carburetor barrel.....                               |                                                              |                                                                    | 91282    |          |          |
| 174                           | Lock washer, carburetor barrel screw.....                   |                                                              |                                                                    | 92290    |          |          |
| 175                           | Screw, carburetor air bleed.....                            |                                                              | 052                                                                | 93157    |          |          |
| 176                           | Screw, carburetor body.....                                 |                                                              |                                                                    | 91284    | 90200    | 90200.   |
| 177                           | Lock washer, carburetor mounting screw.....                 |                                                              |                                                                    |          | 91199    | 91199.   |
| 178                           | Plug, carburetor drain.....                                 | 15238                                                        |                                                                    | 63165    |          |          |
| 179                           | Screw, $\frac{9}{32}$ x $\frac{1}{2}$ " fillister head..... |                                                              |                                                                    | 90558    |          |          |
| 180                           | Screw, idle adjusting.....                                  |                                                              | 03257                                                              | 23164    |          |          |
| 181                           | Spring, idle adjusting.....                                 |                                                              | 0788                                                               | 26185    |          |          |
| 182                           | Screw, air horn.....                                        |                                                              |                                                                    | 90202    |          |          |
| 183                           | Cover and seat, carburetor.....                             | 18020                                                        |                                                                    | 29915    |          |          |
| 184                           | Elbow, inlet connection.....                                |                                                              |                                                                    | 63745    |          |          |
| 185                           | Washer, fiber inlet, lower.....                             |                                                              |                                                                    | 65724    |          |          |
| 186                           | Washer, fiber inlet, upper.....                             |                                                              |                                                                    | 65734    |          |          |
| 187                           | Nut, carburetor cover.....                                  |                                                              |                                                                    | 91692    |          |          |
| 188                           | Lock washer.....                                            | 4351                                                         |                                                                    |          |          |          |
| w                             | Float bowl cover assembly.....                              |                                                              | 04971                                                              |          |          |          |
|                               | Includes items.....                                         |                                                              | 189 to 200                                                         |          |          |          |
| 189                           | Pin, float lever pinion.....                                |                                                              | 03369                                                              |          |          |          |
| 190                           | Cover, float bowl.....                                      |                                                              | 01794                                                              |          |          |          |
| 191                           | Screw, float bowl cover vent.....                           |                                                              | 01434                                                              |          |          |          |
| 192                           | Lock washer, float bowl cover vent screw.....               |                                                              | 0759                                                               |          |          |          |
| 193                           | Gasket, float bowl cover.....                               |                                                              | 01845                                                              |          |          |          |
| 194                           | Screw, float plug.....                                      |                                                              | 02744                                                              |          |          |          |

|     |                                                                        |             |        |
|-----|------------------------------------------------------------------------|-------------|--------|
| 195 | Connector, inlet.....                                                  | 03453.      | 21216. |
| 196 | Screw, inlet connector.....                                            | 02409.      | 68897. |
| 197 | Gasket, inlet connector screw.....                                     | 02410.      | 68887. |
| 198 | Gasket, inlet seat.....                                                | 0337.       | 22032. |
| 199 | Inlet needle and seat assembly.....                                    | 04050.      | 23227. |
| 200 | Seat, inlet valve.....                                                 | 04043.      | 22050. |
| 201 | Venturi.....                                                           |             | 90029. |
| 202 | Gasket, venturi.....                                                   |             | 90369. |
| 203 | Packing, needle valve.....                                             |             | 92017. |
| 204 | Washer, needle valve packing.....                                      |             | 99636. |
| 205 | Nut, needle valve packing.....                                         |             | 68877. |
| 206 | Choke valve, carburetor.....                                           |             | 89428. |
| 207 | Screw, choke valve ( $\frac{3}{16}$ x $\frac{1}{4}$ " round head)..... |             |        |
| 208 | Lock washer, choke valve (No. 4).....                                  |             |        |
| 209 | Screw, swivel.....                                                     |             |        |
| 210 | Valve and seat, inlet.....                                             |             |        |
| 211 | Gasket, inlet valve seat.....                                          |             |        |
| 212 | Choke shaft and lever assembly.....                                    |             |        |
| 213 | Includes items.....                                                    |             |        |
| 214 | Choke lever assembly.....                                              | 04865.      |        |
| 215 | Shaft, choke.....                                                      | 212 to 226. |        |
| 216 | Shutter, choke.....                                                    | 04911.      |        |
| 217 | Screw, choke shutter retaining.....                                    | 04912.      |        |
| 218 | Lever, choke stop.....                                                 | 04863.      |        |
| 219 | Pin, choke stop lever retaining.....                                   | 0120.       |        |
| 220 | Choke lever and swivel assembly.....                                   | 04106.      |        |
| 221 | Choke lever.....                                                       | 03208.      |        |
| 222 | Pin, choke lever retaining.....                                        | 05994.      |        |
| 223 | Screw, choke lever clamp.....                                          | 01830.      |        |
| 224 | Peg, choke lever stop.....                                             |             |        |
| 225 | Swivel, choke lever.....                                               | 0240.       |        |
| 226 | Washer, choke lever swivel.....                                        | 05006.      |        |
| 227 | Screw, choke lever swivel.....                                         | 05680.      |        |
| 228 | Spring, choke lever return.....                                        | 04920.      |        |
| 229 | Throttle and lever assembly.....                                       | 058.        |        |
| 230 | Includes items.....                                                    | 04122.      |        |
| 231 | Shaft, throttle.....                                                   | 04864.      |        |
| 232 | Shutter, throttle.....                                                 | 227 to 248. |        |
| 233 | Screw, throttle shutter retaining.....                                 | 05553.      |        |
| 234 | Throttle lever and swivel assembly.....                                | 04119.      |        |
| 235 |                                                                        | 0120.       |        |
| 236 |                                                                        | 05992.      |        |

| A.                 | B                                                                         | C                                         | D                                               | E        | F                                             | G          |
|--------------------|---------------------------------------------------------------------------|-------------------------------------------|-------------------------------------------------|----------|-----------------------------------------------|------------|
| Item reference No. | Name of item                                                              | PE-HA-43                                  | PE-HB-43                                        | PE-HC-43 | PE-HD-43                                      | PE-HE-43   |
|                    |                                                                           | Homelite Corporation, Port Chester, N. Y. | United States Motors Corporation, Oshkosh, Wis. |          | Climax Engineering Corporation, Clinton, Iowa |            |
| 231                | Screw, throttle lever retaining.....                                      |                                           | 061.....                                        |          |                                               |            |
| 232                | Swivel, throttle lever.....                                               |                                           | 05680.....                                      |          |                                               |            |
| 233                | Washer, throttle lever swivel.....                                        |                                           | 04920.....                                      |          |                                               |            |
| 234                | Lever, throttle shaft.....                                                |                                           | 04107.....                                      |          |                                               |            |
| 235                | Peg, throttle lever stop.....                                             |                                           | 03517.....                                      |          |                                               |            |
| 236                | Tip, nozzle.....                                                          |                                           | 04118.....                                      |          |                                               |            |
| 237                | Nozzle, shank.....                                                        |                                           | 04202.....                                      |          |                                               |            |
| 238                | Gasket, main nozzle.....                                                  |                                           | 02817.....                                      |          |                                               |            |
| 239                | Gland, main adjustment screw.....                                         |                                           | 0702.....                                       |          |                                               |            |
| 240                | Packing, main adjustment screw gland.....                                 |                                           | 0705.....                                       |          |                                               |            |
| 241                | Nut, main adjustment screw packing.....                                   |                                           | 0703.....                                       |          |                                               |            |
| 242                | Gasket, main adjustment screw gland.....                                  |                                           | 0676.....                                       |          |                                               |            |
| 243                | Screw, main adjustment.....                                               |                                           | 03076.....                                      |          |                                               |            |
| 244                | Cross bar.....                                                            |                                           | 0700.....                                       |          |                                               |            |
| 245                | Stem.....                                                                 |                                           | 0701.....                                       |          |                                               |            |
| 246                | Needle.....                                                               |                                           | 03075.....                                      |          |                                               |            |
| 247                | Plug, body.....                                                           |                                           | 03575.....                                      |          |                                               |            |
| 248                | Body.....                                                                 |                                           | 05541.....                                      |          |                                               |            |
| 249                | Bushing, throttle shaft.....                                              |                                           |                                                 |          | 23230.....                                    | 23230..... |
| 250                | Upper body, carburetor.....                                               |                                           |                                                 |          | 99954.....                                    | 99954..... |
| 251                | Spring, idler valve.....                                                  |                                           |                                                 |          | 26157.....                                    | 26157..... |
| 252                | Valve, idler needle.....                                                  |                                           |                                                 |          | 23228.....                                    | 23228..... |
| 253                | Valve, carburetor throttle.....                                           |                                           |                                                 |          | 22036.....                                    | 22036..... |
| 254                | Screw, throttle valve ( $\frac{3}{32}$ x $\frac{1}{2}$ " round head)..... |                                           |                                                 |          | 90029.....                                    | 90029..... |
| 255                | Lock washer, throttle valve screw (No. 4).....                            |                                           |                                                 |          | 90369.....                                    | 90369..... |
| 256                | Stop, throttle.....                                                       |                                           |                                                 |          | 61967.....                                    | 61967..... |
| 257                | Throttle shaft assembly.....                                              |                                           |                                                 |          | 99635.....                                    | 99635..... |
| 258                | Lever, throttle.....                                                      |                                           |                                                 |          | 21152.....                                    | 21152..... |
| 259                | Pin, throttle stop and lever.....                                         |                                           |                                                 |          | 23125.....                                    | 23125..... |
| 260                | Spring, throttle stop.....                                                |                                           |                                                 |          | 26119.....                                    | 26119..... |
| 261                | Screw, throttle stop spring.....                                          |                                           |                                                 |          | 91920.....                                    | 91920..... |

|      |                                          |          |            |            |             |
|------|------------------------------------------|----------|------------|------------|-------------|
| 262  | Elbow, rburetor connector                |          |            |            | 63377.      |
| 263  | Wire, c hoke                             | A-351    |            |            |             |
| 264  | Conduit, choke                           | A-350    |            |            |             |
| 265  | Clip, choke wire conduit                 | A-347    |            |            |             |
| 266  | Clip, loop                               | A-348    |            |            |             |
| 267  | Button, choke                            | A-349    |            |            |             |
| 268  | Bowl, fuel filter                        |          | 68487      | 68487      | 68487.      |
| 269  | Yoke, fuel filter                        |          | 90665      | 90665      | 90665.      |
| 270  | Screen, filter                           |          | 62876      | 62876      | 62876.      |
| 271  | Gasket, filter                           |          | 68477      | 68477      | 68477.      |
| z    | Fuel filter cover assembly               |          | 99909      | 99909      | 99909.      |
|      | Includes items                           |          | 272 to 275 | 272 to 275 | 272 to 275. |
| 272  | Nipple, fuel tank                        |          | 91635      | 91635      | 91635.      |
| 273  | Connector, filter                        |          | 53029      | 53029      | 53029.      |
| 274  | Lever, shut-off                          |          | 23347      | 23347      | 23347.      |
| 275  | Nut, shut-off lever retaining            |          | 23346      | 23346      | 23346.      |
| 276  | Packing, shut-off lever                  |          | 27019      | 27019      | 27019.      |
| 277  | Elbow, carburetor intake                 |          | 21195      | 21195      | 21195.      |
| 278  | Gasket, intake elbow                     |          | 68987      | 68987      | 68987.      |
| 278A | Lock nut, intake elbow                   |          | 23345      | 23345      | 23345.      |
| 278B | Screw, intake elbow mounting             |          | 91422      | 91422      | 91422.      |
| 278C | Lock washer, intake elbow mounting screw |          | 90832      | 90832      | 90832.      |
| 278D | Line, fuel                               |          | 89227      | 89227      | 89227.      |
| 279  | Screw, choke retainer                    | H-50     |            |            |             |
| 280  | Lock washer, choke retainer screw        | H-351    |            |            |             |
| 281  | Bowl, air cleaner                        |          | 29681      | 29681      | 29681.      |
| 282  | Filter, air cleaner                      |          | 29680      | 29680      | 29680.      |
| 283  | Gasket, air cleaner cover                |          | 67897      | 67897      | 67897.      |
| 284  | Cover, air cleaner                       |          | 29679      | 29679      | 29679.      |
| 285  | Stem, air cleaner                        |          | 63733      | 63733      | 63733.      |
| 286  | Wing nut, air cleaner                    |          | 91674      | 91674      | 91674.      |
| 287  | Gasket, air cleaner                      |          | 67247      | 67247      | 67247.      |
| 288  | Air cleaner, Donaldson                   | RA-413   |            |            |             |
| 289  | Elbow, air cleaner                       | RA-383-A |            |            |             |
| 290  | Screw, $\frac{3}{8}$ x $1\frac{1}{2}$ "  | 8-32V18  |            |            |             |
| 291  | Pipe, air cleaner                        |          | 61664      | 61664      | 61664.      |
| 292  | Screw, air cleaner pipe                  |          | 91256      | 91256      | 91256.      |
| 2.23 | Strap, air cleaner mounting, upper       |          | 62446      | 62446      | 62446.      |
| 294  | Strap, air cleaner mounting, lower       |          | 62447      | 62447      | 62447.      |
| 295  | Screw, air cleaner mounting              |          | 90950      | 90950      | 90950.      |

| A                  | B                                       | C                                         | D                                               | E        | F        | G                                             |
|--------------------|-----------------------------------------|-------------------------------------------|-------------------------------------------------|----------|----------|-----------------------------------------------|
| Item reference No. | Name of item                            | PE-HA-43                                  | PE-HB-43                                        | PE-HC-43 | PE-HD-43 | PE-HE-43                                      |
|                    |                                         | Homelite Corporation, Port Chester, N. Y. | United States Motors Corporation, Oshkosh, Wis. |          |          | Climax Engineering Corporation, Clinton, Iowa |
| 296                | Nut, air cleaner mounting screw         |                                           |                                                 | 91208    |          |                                               |
| 297                | Lock washer, air cleaner mounting screw |                                           |                                                 | 90366    |          |                                               |
| 298                | Spacer, air cleaner pipe                |                                           |                                                 | 63848    |          |                                               |
| 299                | Stud, air cleaner pipe                  |                                           |                                                 | 63849    |          |                                               |
| 300                | Nut, air cleaner pipe stud              |                                           |                                                 | 91744    |          |                                               |
| 301                | Pipe, intake                            |                                           | RA-319-D                                        |          |          |                                               |
| 302                | Gasket, intake pipe                     |                                           | RA-293                                          |          |          |                                               |
| 303                | Gasket, carburetor to intake pipe       |                                           | RA-295                                          |          |          |                                               |
| 304                | Screw, intake pipe                      |                                           | 4-C-05                                          |          |          |                                               |
| 305                | Lock washer, intake pipe screw          |                                           | 4-W                                             |          |          |                                               |
| 306                | Nut, intake pipe                        | 10567                                     |                                                 |          |          |                                               |
| 307                | Spring, intake pipe nut retaining       | 15219                                     |                                                 |          |          |                                               |
| 308                | Screw, carburetor mounting              |                                           |                                                 | 91691    |          |                                               |
| 309                | Lock washer, carburetor mounting screw  |                                           |                                                 | 90832    |          |                                               |
| 310                | Brace, air cleaner elbow                |                                           |                                                 |          | 22135    | 22135.                                        |
| 311                | Screw, elbow mounting brace             |                                           |                                                 |          | 90891    | 90891.                                        |
| 312                | Lock washer, elbow brace mounting screw |                                           |                                                 |          | 90832    | 90832.                                        |
| 313                | Lock nut, elbow mounting brace          |                                           |                                                 |          | 92129    | 92129.                                        |
| 314                | Lock washer, elbow brace lock nut       |                                           |                                                 |          | 90832    | 90832.                                        |
| 315                | Screw, elbow mounting                   |                                           |                                                 |          | 92134    | 92134.                                        |
| 316                | Lock washer, elbow mounting screw       |                                           |                                                 |          | 90832    | 90832.                                        |
| 317                | Washer, elbow mounting screw            |                                           |                                                 |          | 22144    | 22144.                                        |
| 318                | Lock nut, elbow mounting screw          |                                           |                                                 |          | 92129    | 92129.                                        |
| aa                 | Magneto assembly                        | 15005                                     | 23125                                           | 29120    | 89426    | 89426.                                        |
|                    | Includes items                          |                                           | 319 to 357                                      |          |          |                                               |
| ab                 | Magneto stator assembly                 |                                           | 23128                                           |          |          |                                               |
|                    | Includes items                          |                                           | 319 to 321                                      |          |          |                                               |
| ac                 | Magneto winding assembly                |                                           |                                                 |          |          |                                               |
|                    | Includes items                          |                                           | 322 to 327                                      |          |          |                                               |
| ad                 | Magneto capacitor assembly              |                                           |                                                 |          |          |                                               |
|                    | Includes items                          |                                           | 328 to 334                                      |          |          |                                               |

49



| A                             | B                                                 | C                                            | D                                                  | E        | F        | G                                                  |
|-------------------------------|---------------------------------------------------|----------------------------------------------|----------------------------------------------------|----------|----------|----------------------------------------------------|
| Item<br>refer-<br>ence<br>No. | Name of item                                      | PE-HA-43                                     | PE-HB-43                                           | PE-HC-43 | PE-HD-43 | PE-HE-43                                           |
|                               |                                                   | Homelite Corporation,<br>Port Chester, N. Y. | United States Motors Corporation,<br>Oshkosh, Wis. |          |          | Climax Engineering Corporation, Clin-<br>ton, Iowa |
| 353                           | Washer, breaker lever spacing (0.050" thick)      |                                              | 20481                                              |          |          |                                                    |
| 354                           | Washer, breaker lever spacing (0.016" thick)      |                                              | 20547                                              |          |          |                                                    |
| 355                           | Washer, breaker lever spacing (0.008" thick)      |                                              | 20485                                              |          |          |                                                    |
| 356                           | Wick, breaker lever bearing oil                   |                                              | 20484                                              |          |          |                                                    |
| 357                           | Plate, breaker, with contact screw                |                                              | 22018                                              |          |          |                                                    |
| 358                           | Screw, contact block                              |                                              |                                                    | 63369    | 63369    | 63369                                              |
| 359                           | Lock washer, contact block screw                  |                                              |                                                    | 90367    | 90367    | 90367                                              |
| 360                           | Stop, contact spring                              |                                              |                                                    | 62100    | 62100    | 62100                                              |
| 361                           | Point and spring, contact                         |                                              |                                                    | 69754    | 69754    | 69754                                              |
| 362                           | Block, contact spring                             |                                              |                                                    | 65078    | 65078    | 65078                                              |
| 363                           | Nut, contact block                                |                                              |                                                    | 90313    | 90313    | 90313                                              |
| 364                           | Bearing, magneto, with oil retaining ring         |                                              |                                                    | 69911    | 69911    | 69911                                              |
| 365                           | Ring, oil retaining                               |                                              |                                                    | 62235    | 62235    | 62235                                              |
| 366                           | Screw, magneto mounting                           | 11674                                        |                                                    | 91385    | 91385    | 19385                                              |
| 367                           | Lock washer, magneto mounting screw               | H-169                                        |                                                    | 91388    | 91388    | 91388                                              |
| 368                           | Terminal, ignition cable                          | 15310                                        | RA-518-A                                           |          |          |                                                    |
| 369                           | Cable, ignition                                   |                                              | RA-207-A                                           | See 369A | See 369A | See 369A.                                          |
| 369A                          | Cable, ignition (not included in assembly aa)     | 15309                                        |                                                    | 29147    | 29147    | *29147.                                            |
| 370                           | Brusk holder, magneto                             | 10590                                        |                                                    |          |          |                                                    |
| 371                           | Gasket, magneto bracket                           |                                              |                                                    | 66527    | 66527    | 66527                                              |
| 372                           | Gasket, magneto plate (0.005" thick)              |                                              |                                                    | 66537    | 66537    | 66537                                              |
| 373                           | Gasket, magneto plate (0.009" thick) <sup>1</sup> |                                              |                                                    | 66457    | 66457    | 66457                                              |
| 374                           | Gasket, magneto plate (0.015" thick) <sup>1</sup> |                                              |                                                    | 89085    | 89085    | 89085                                              |
| 375                           | Plate, magneto                                    |                                              |                                                    | 29656    | 29656    | 29656                                              |
| 376                           | Armature, magneto                                 |                                              |                                                    | 62178    | 62178    | 62178                                              |
| 377                           | Plate, contact block connector                    |                                              |                                                    | 65725    | 65725    | 65725                                              |
| 378                           | Insulator, armature lead                          |                                              |                                                    | 65735    | 65735    | 65735                                              |
| 379                           | Insulator, capacitor lead                         |                                              |                                                    | 91270    | 91270    | 91270                                              |
| 380                           | Screw, armature mounting                          |                                              |                                                    | 90832    | 90832    | 90832                                              |
| 381                           | Lock washer, armature mounting screw              |                                              |                                                    | 68876    | 68876    | 68876                                              |
| 382                           | Clip, dust cover                                  |                                              |                                                    |          |          |                                                    |

|     |                                                    |       |                 |              |              |
|-----|----------------------------------------------------|-------|-----------------|--------------|--------------|
| 383 | Dust cover, magneto point.....                     |       | 65198.....      | 65198.....   | 65198.....   |
| 384 | Plunger, magneto.....                              |       | 65414.....      | 65414.....   | 65414.....   |
| 385 | Air guide, magneto plate.....                      |       | 29107.....      | 22309.....   | 22309.....   |
| 386 | Valve, oil return.....                             |       | 89307.....      | 89307.....   | 89307.....   |
| ca  | Fuel tank assembly.....                            |       | RA-2429-1.....  |              |              |
|     | Includes items.....                                |       | 387 to 401..... |              |              |
| ai  | Bare fuel tank assembly.....                       |       | RA-1429-1.....  |              |              |
|     | Includes items.....                                |       | 387 to 391..... |              |              |
| aj  | Filler cap assembly.....                           |       | RA-1312-1.....  |              |              |
|     | Includes items.....                                |       | 396 to 401..... |              |              |
| 387 | Flange, fuel line.....                             |       | W-144.....      |              |              |
| 388 | Flange, fuel tank filler.....                      |       | RA-313.....     |              |              |
| 389 | Cap, fuel tank.....                                | 18029 |                 |              |              |
| 390 | Head, fuel tank.....                               |       | RA-379-A.....   |              |              |
| 391 | Sheet, fuel tank body.....                         |       | RA-429-O.....   |              |              |
| 392 | Tank, fuel.....                                    |       |                 | C-411-P..... | C-411-P..... |
| 393 | Pipe, fuel.....                                    |       | RA-115-B.....   |              |              |
| 394 | Sleeve, compression coupling.....                  |       | 60-F-3/16.....  |              |              |
| 395 | Nut, compression coupling.....                     |       | 61-F-3/16.....  |              |              |
| 396 | Cap, fuel tank.....                                |       | RA-312.....     | 01-822.....  | 01-822.....  |
| 397 | Washer, fuel tank cap.....                         |       | RA-311.....     |              |              |
| 398 | Screen, fuel tank cap.....                         |       | RA-314.....     |              |              |
| 399 | Chain, fuel tank cap.....                          |       | RA-302.....     |              |              |
| 400 | Pin, cotter, $\frac{3}{32}$ x $\frac{5}{16}$ ..... |       | 6-P-05.....     |              |              |
| 401 | Cross bar, fuel tank cap.....                      |       | RA-535.....     |              |              |
| 402 | Bracket, fuel tank.....                            |       | RA-324-B.....   | 21198.....   | 21198.....   |
| 403 | Strap, fuel tank.....                              |       | RA-409-A.....   | 69298.....   | 69298.....   |
| 404 | Screw, fuel tank strap.....                        |       | 4-G-05.....     |              |              |
| 405 | Screw, fuel tank bracket.....                      |       | 4-G-05.....     | 92147.....   | 92147.....   |
| 406 | Lock washer, fuel tank bracket screw.....          |       | 4-W.....        | 90683.....   | 90683.....   |
| 407 | Nut and bolt, fuel tank strap.....                 |       |                 | 91568.....   | 91568.....   |
| ak  | Base assembly.....                                 |       | RA-1015-5.....  |              |              |
|     | Includes items.....                                |       | 408 to 416..... |              |              |
| al  | Crankcase end plate assembly.....                  |       | RA-1084-4.....  |              |              |
|     | Includes items.....                                |       | 419, 420.....   |              |              |
| am  | Main bearing housing assembly.....                 |       | RA-1109-4.....  |              |              |
|     | Includes items.....                                |       | 417, 418.....   |              |              |
| 408 | Pan, oil splash.....                               |       | RA-193.....     |              |              |

<sup>1</sup> Denotes an oversize repair item which is not required except when replacing to compensate for wear in other parts.

| A                  | B                                                             | O                                         | D                                               | E          | F          | G                                             |
|--------------------|---------------------------------------------------------------|-------------------------------------------|-------------------------------------------------|------------|------------|-----------------------------------------------|
| Item reference No. | Name of item                                                  | PE-HA-43                                  | PE-HB-43                                        | PE-HC-43   | PE-HD-43   | PE-HE-43                                      |
|                    |                                                               | Homelite Corporation, Port Chester, N. Y. | United States Motors Corporation, Oshkosh, Wis. |            |            | Climax Engineering Corporation, Clinton, Iowa |
| 409                | Base.....                                                     |                                           | RA-15-H.....                                    | 61473..... | 61473..... | 61473.....                                    |
| 410                | Studs, crankcase to base.....                                 |                                           | RA-68-A.....                                    |            |            |                                               |
| 411                | Ell, street, 3/4".....                                        |                                           | 8-AC.....                                       |            |            |                                               |
| 412                | Plug, oil drain pipe, 1/4".....                               |                                           | 2-Z.....                                        | 90878..... | 90878..... | 90878.....                                    |
| 413                | Plug, oil filler pipe, 3/4".....                              |                                           | 6-Z.....                                        | 90886..... | 90886..... | 90886.....                                    |
| 414                | Screw, base.....                                              |                                           | 6-C-06.....                                     |            |            |                                               |
| 415                | Lock washer, base screw.....                                  |                                           | 5-W.....                                        |            |            |                                               |
| 416                | Screw, round head cap.....                                    |                                           | 4-V-06.....                                     |            |            |                                               |
| 417                | Housing, main bearing.....                                    |                                           | RA-109-F.....                                   |            |            |                                               |
| 418                | Cup, bearing.....                                             |                                           | RA-427.....                                     |            |            |                                               |
| 419                | Cup, bearing.....                                             |                                           | RA-427.....                                     |            |            |                                               |
| 420                | Plate, crankcase end.....                                     |                                           | RA-64-K.....                                    |            |            |                                               |
| 421                | Nut, base.....                                                | 11616.....                                |                                                 |            |            |                                               |
| 422                | Lock washer, base nut, upper.....                             | 6540.....                                 |                                                 |            |            |                                               |
| 423                | Lock washer, base nut, lower.....                             | 11679.....                                |                                                 |            |            |                                               |
| 424                | Foot.....                                                     | 10502.....                                |                                                 |            |            |                                               |
| 425                | Stud, crankcase side plate.....                               |                                           | RA-68-A.....                                    |            |            |                                               |
| 426                | Gasket, crankcase and plate.....                              |                                           | RA-121-A.....                                   |            |            |                                               |
| 427                | Gasket, main bearing housing.....                             |                                           | RA-126.....                                     |            |            |                                               |
| 428                | Gasket, base.....                                             |                                           | RA-132-B.....                                   | 66987..... | 66987..... | 66987.....                                    |
| 429                | Gasket, crankcase end plate (thin).....                       |                                           | RA-246-A.....                                   |            |            |                                               |
| 430                | Gasket, breather body.....                                    |                                           | RA-397-A.....                                   |            |            |                                               |
| 431                | Nut, crankcase end plate and bearing housing.....             |                                           | 5-K.....                                        |            |            |                                               |
| 432                | Lock washer, crankcase end plate and bearing housing nut..... |                                           | 5-W.....                                        |            |            |                                               |
| 433                | Screw, breather.....                                          |                                           | 4-G-112.....                                    |            |            |                                               |
| 434                | Lock washer, breather screw.....                              |                                           | 4-W.....                                        |            |            |                                               |
| 435                | Washer, oil seal.....                                         |                                           | RA-167-A.....                                   | 99175..... | 99175..... | 99175.....                                    |
| 436                | Nipple, oil filler.....                                       |                                           |                                                 | 91523..... | 91523..... | 91523.....                                    |
| 437                | Cap, oil filler.....                                          |                                           |                                                 | 69345..... | 69345..... | 69345.....                                    |
| 438                | Bearing, ball.....                                            | 11266.....                                |                                                 | 99157..... | 99157..... | 99157.....                                    |

|      |                                                  |       |            |       |        |
|------|--------------------------------------------------|-------|------------|-------|--------|
| 439  | Screw, base.....                                 |       | 90887      | 90887 | 90887. |
| 440  | Lock washer, base screw.....                     |       | 92268      | 92268 | 92268. |
| 441  | Ring, main bearing retainer.....                 | 11267 |            |       |        |
| 442  | Washer, cork, main bearing.....                  | 11271 |            |       |        |
| 443  | Facing, cork, main bearing.....                  | 11377 |            |       |        |
| 444  | Gasket, crankcase back plate.....                | 11089 |            |       |        |
| 445  | Screw, crankcase.....                            | 10491 |            |       |        |
| 446  | Lock washer, crankcase screw.....                | 10485 |            |       |        |
| an   | Blower housing assembly.....                     |       |            |       |        |
|      | Includes items.....                              |       | RA-2014-5  |       |        |
| ao   | Stop switch assembly.....                        |       | 447 to 455 |       |        |
|      | Includes items.....                              |       | RA-1179    |       |        |
| ap   | Blower housing back plate assembly complete..... |       | 453 to 455 |       |        |
|      | Includes items.....                              |       | RA-2101-2  |       |        |
| aq   | Blower housing back plate assembly.....          |       | 456 to 459 |       |        |
|      | Includes items.....                              |       | RA-1101-2  |       |        |
| 447  | Flywheel and blower.....                         |       | 456, 457   | 61451 | 61451. |
| 448  | Bare blower housing assembly.....                |       | 23126      |       |        |
| 449  | Housing, blower.....                             |       | RA-1104-5  |       |        |
| 450  | Plate, tapping.....                              |       | RA-104-C   | 29098 | 99929. |
| 451  | Deflector, air.....                              |       | RA-499     |       |        |
| 452  | Rivets, switch spring.....                       |       | RA-289-A   |       |        |
| 453  | Button, stop switch.....                         |       | I-AL       |       |        |
| 454  | Grommet.....                                     |       | RA-179     |       |        |
| 455  | Spring, stop switch.....                         |       | RA-488     |       |        |
| 456  | Plate, blower housing, back.....                 |       | RA-180     |       |        |
| 457  | Plate, tapping.....                              |       | RA-101-F   |       |        |
| 457A | Nut, switch screw.....                           |       | RA-499     |       |        |
| 457B | Bushing, switch insulating.....                  |       | 8-32-AG    |       |        |
| 458  | Washer, switch insulator.....                    |       | RA-91      |       |        |
| 459  | Screw, switch.....                               |       | RA-92      |       |        |
| 460  | Screw, blower housing.....                       | 11595 | 8-32-V-20  | 92272 | 92272. |
| 461  | Lock washer, blower housing screw.....           | H-169 |            | 90366 | 90366. |
| 462  | Screw, handle.....                               | 11674 |            |       |        |
| 463  | Lock washer, handle screw.....                   | H-169 |            |       |        |
| 464  | Screw, Parker-Kalon, name plate.....             |       | 4-AO-4     |       |        |
| 465  | Plate, name.....                                 |       | RA-492     |       |        |
| 466  | Cover, blower housing.....                       |       | RA-120-A   |       |        |
| 467  | Bracket, blower housing mounting.....            |       |            | 62177 | 62177. |
| 468  | Screw, blower housing mounting.....              |       |            | 90916 | 90916. |

| A                        | B                                          | C                                                            | D                                                                  | E        | F        | G        |
|--------------------------|--------------------------------------------|--------------------------------------------------------------|--------------------------------------------------------------------|----------|----------|----------|
| Item<br>reference<br>No. | Name of item                               | PE-HA-43<br><br>Homelite Corporation,<br>Port Chester, N. Y. | PE-HB-43<br><br>United States Motors Corporation,<br>Oshkosh, Wis. | PE-HC-43 | PE-HD-43 | PE-HE-43 |
| 469                      | Lock washer, blower housing mounting screw |                                                              |                                                                    | 90832    | 90832    | 90832    |
| 470                      | Screen, blower                             |                                                              |                                                                    | 62347    | 62347    | 62347    |
| 471                      | Rivet, blower screen                       |                                                              |                                                                    | 36436    | 36436    | 36436    |
| 472                      | Puller, flywheel                           |                                                              |                                                                    | 29157    | 29157    | 29157    |
| 473                      | Lock washer, adjusting screw               | 10485                                                        |                                                                    |          |          |          |
| 474                      | Coil, 32 volt                              | 11650                                                        |                                                                    |          |          |          |
| 475                      | Nut, molded                                | 15070                                                        |                                                                    |          |          |          |
| as                       | Muffler assembly                           |                                                              | RA-1002                                                            | 89567    | 89567    | 89567    |
|                          | Includes items                             |                                                              | 476 to 480                                                         |          |          |          |
| 476                      | Plate, muffler inlet                       |                                                              | WM-1                                                               |          |          |          |
| 477                      | Plate, muffler outlet                      |                                                              | WM-2                                                               |          |          |          |
| 478                      | Coupling, muffler                          |                                                              | RA-443                                                             |          |          |          |
| 479                      | Rivet                                      |                                                              | 3-A-L                                                              |          |          |          |
| 480                      | Burr                                       |                                                              | 7-A-M                                                              |          |          |          |
| 481                      | Elbow, muffler                             |                                                              |                                                                    | 91205    | 91205    | 91205    |
| 482                      | Muffler                                    | 18015                                                        |                                                                    |          |          |          |
| 483                      | Lock nut, muffler elbow                    |                                                              |                                                                    | 91242    | 91242    | 91242    |
| 484                      | Nipple, muffler                            |                                                              | RA-483                                                             | 91245    | 91245    | 91245    |
| 485                      | Rope, starting                             | 11408                                                        |                                                                    | 66979    | 66979    | 66979    |
| 486                      | Pulley, rope starter                       |                                                              | RA-264-A                                                           | 61492    | 61492    | 61492    |
| 487                      | Pin, starter pulley                        | 10535                                                        |                                                                    |          |          |          |
| 488                      | Screw, starter pulley                      | 11598                                                        |                                                                    |          |          |          |
| 489                      | Washer, pulley screw                       | 11599                                                        |                                                                    |          |          |          |
| 490                      | Nut, extension, starter pulley             |                                                              | RA-263-A                                                           |          |          |          |
| 491                      | Nut, starter pulley                        |                                                              | 9-K                                                                |          |          |          |
| 492                      | Screw, engine end cover                    | 10495                                                        |                                                                    |          |          |          |
| 493                      | Lock washer, engine end cover screw        | 10485                                                        |                                                                    |          |          |          |
| as                       | Generator terminal panel assembly          | 15010                                                        |                                                                    |          |          |          |
|                          | Includes items                             | 494, 495                                                     |                                                                    |          |          |          |
| 494                      | Receptacle                                 | 15100                                                        |                                                                    | 10108    | 10108    | 10108    |
| 495                      | Nut, molded terminal                       | 15071                                                        |                                                                    |          |          |          |

|     |                                             |          |           |  |           |  |            |
|-----|---------------------------------------------|----------|-----------|--|-----------|--|------------|
| 496 | Screw, mounting.....                        | 10491    |           |  |           |  |            |
| 497 | Lock washer, mounting screw.....            | 10485    |           |  |           |  |            |
| 498 | Panel, terminal (blank).....                |          | SC-30     |  | C-669-A   |  | C-669-A.   |
| 499 | Bracket, terminal panel, left hand.....     |          | SC-35     |  | C-394-E   |  | C-394-E.   |
| 500 | Bracket, terminal panel, right hand.....    |          | SC-34     |  | C-394-D   |  | C-394-D.   |
| 501 | Cable, negative, long.....                  | 11590    |           |  |           |  |            |
| 502 | Cable, positive, short.....                 | 11589    |           |  |           |  |            |
| 503 | Cable, regulator to terminal plate.....     | 15051    |           |  |           |  |            |
| 504 | Regulator, voltage, 32 volt.....            | 15230    |           |  |           |  |            |
| 505 | Binding post, terminal.....                 |          | 45.       |  | 45.       |  | 45.        |
| at  | Armature assembly.....                      | 10758    | G-3596    |  | G-3596    |  | G-3596.    |
|     | Includes items.....                         | 506, 507 |           |  |           |  |            |
| 506 | Armature.....                               | 15155    |           |  |           |  |            |
| 507 | Fan and bushing assembly.....               |          | G-3597    |  | G-3597    |  | G-3597.    |
| au  | Field frame and coil assembly.....          | 10766    |           |  |           |  |            |
|     | Includes items.....                         | 508, 509 |           |  |           |  |            |
| 508 | Casting, field frame.....                   |          | P-5746    |  | P-5746    |  | P-5746.    |
| 509 | Coil assembly, field.....                   |          | G-3599    |  | G-3599    |  | G-3599.    |
| 510 | Shoe assembly, pole.....                    |          | G-1610    |  | G-1610    |  | G-1610.    |
| 511 | Retainer, field pole.....                   |          | P-2317    |  | P-2317    |  | P-2317.    |
| 512 | Screw, field pole retainer.....             |          | P-5592    |  | P-5592    |  | P-5592.    |
| 513 | Lock washer, field pole retainer screw..... |          | P-5593    |  | P-5593    |  | P-5593.    |
| 514 | Grommet, insulating.....                    |          | GR-A-5848 |  | GR-A-5848 |  | GR-A-5848. |
| av  | Brush assembly.....                         | 11476    |           |  |           |  |            |
|     | Includes items.....                         | 515, 516 |           |  |           |  |            |
| 515 | Spring, generator brush.....                | H-193    |           |  |           |  |            |
| 516 | Lead, brush.....                            | 15048    |           |  |           |  |            |
| 517 | Holder, brush.....                          | 15120    |           |  |           |  |            |
| 518 | Screw, brush holder.....                    |          | G-2963    |  | G-2963    |  | G-2963.    |
| 519 | Screw, brush terminal.....                  |          | G-3731    |  | G-3731    |  | G-3731.    |
| 520 | Lead and lug assembly (jumper).....         |          | P-4581    |  | P-4581    |  | P-4581.    |
| 521 | Retainer brush.....                         |          | P-5763    |  | P-5763    |  | P-5763.    |
| 522 | Lock washer, brush holder screw.....        |          | G-2894    |  | G-2894    |  | G-2894.    |
| 523 | Lock washer, brush terminal screw.....      |          | P-1886    |  | P-1886    |  | P-1886.    |
| 524 | Screw, end plate.....                       | 10704    | P-3852    |  | P-3852    |  | P-3852.    |
| 525 | Washer, brass, plain.....                   | 15142    | P-3515    |  | P-3515    |  | P-3515.    |
| 526 | Washer, insulating fiber.....               | 15143    |           |  |           |  |            |
| 527 | Ring, insulating.....                       | 10786    |           |  |           |  |            |
| 528 | Nut, binding post.....                      | 15032    |           |  |           |  |            |
| 529 | Lock washer, end plate screw.....           | H-169    |           |  |           |  |            |

| A                             | B                                      | C                                            | D                                                  | E          | F        | G                                                  |
|-------------------------------|----------------------------------------|----------------------------------------------|----------------------------------------------------|------------|----------|----------------------------------------------------|
| Item<br>refer-<br>ence<br>No. | Name of item                           | PE-HA-43                                     | PE-HB-43                                           | PE-HC-43   | PE-HD-43 | PE-HE-43                                           |
|                               |                                        | Homelite Corporation,<br>Port Chester, N. Y. | United States Motors Corporation,<br>Oshkosh, Wis. |            |          | Climax Engineering Corporation, Clin-<br>ton, Iowa |
| 530                           | Bearing.....                           | H-154                                        |                                                    |            |          |                                                    |
| 531                           | Bushing, insulating.....               | H-305                                        |                                                    |            |          |                                                    |
| 532                           | Cover, generator.....                  |                                              |                                                    | P-5743     | P-5743   | P-5743.                                            |
| 533                           | Cover, generator end.....              |                                              |                                                    | P-5744     | P-5744   | P-5744.                                            |
| 534                           | Screw, end cover.....                  | 10497                                        |                                                    | P-5734     | P-5734   | P-5734.                                            |
| 535                           | Lock washer, end cover screw.....      | 10485                                        |                                                    | P-3515     | P-3515   | P-3515.                                            |
| 536                           | Adapter, generator.....                |                                              |                                                    | P-I-550-A  | C-641-L  | C-641-L.                                           |
| 537                           | Screw, shell.....                      |                                              |                                                    | P-5734     | P-5734   | P-5734.                                            |
| 538                           | Lock washer, shell screw.....          |                                              |                                                    | P-3852     | P-3852   | P-3852.                                            |
| 539                           | Bushing, shell screw.....              |                                              |                                                    | P-5745     | P-5745   | P-5745.                                            |
| 540                           | Crate assembly.....                    |                                              |                                                    | SC-33      | C-645-B  | C-645-B.                                           |
| 541                           | Skid base assembly.....                |                                              |                                                    | SC-31      | C-576-G  | C-576-G.                                           |
| 542                           | Mounting, rubber.....                  |                                              |                                                    | DA-1090-70 | DA-1090  | DA-1090.                                           |
| 543                           | Handle, crate.....                     |                                              |                                                    | 2082-J-4   | 108      | 108.                                               |
| 544                           | Bolt, clamp, with latch.....           |                                              |                                                    | 240        |          |                                                    |
| 545                           | Lever bolt, upper part.....            |                                              |                                                    |            | 240-U    | 240-U.                                             |
| 546                           | Lever bolt, lower part.....            |                                              |                                                    |            | 240-L    | 240-L.                                             |
| 547                           | Butt, tool box cover hook.....         |                                              |                                                    |            |          |                                                    |
| 548                           | Gate hook and eye, tool box cover..... |                                              |                                                    | 719-M      |          |                                                    |
| 549                           | Hinge, tool box cover.....             |                                              |                                                    | 40-M-9     |          |                                                    |
| 550                           | Scraper, carbon.....                   | 11479                                        |                                                    | 12         |          |                                                    |
| 551                           | Wrench, double end (Armstrong).....    | 25-A                                         |                                                    |            |          |                                                    |
| 552                           | Wrench, socket.....                    | 10865                                        |                                                    |            |          |                                                    |

CHARGING SET SCR-169

| A<br>Item | B<br>Part name                                                                                                                                                                                                                              | BD-LL-61           | BD-LM-61<br>BD-LN-61<br>BD-LO-61<br>BD-LP-61 |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|----------------------------------------------|
|           |                                                                                                                                                                                                                                             | Number<br>required | Number<br>required                           |
|           | <i>aw.</i> Panel BD-61.....                                                                                                                                                                                                                 |                    |                                              |
| 553       | Panel board.....                                                                                                                                                                                                                            | 1                  | 1                                            |
| 554       | Voltmeter IF-47 (0-50 volts, d-c).....                                                                                                                                                                                                      | 1                  | 1                                            |
| 555       | Ammeter IF-16 (0-10 amperes, d-c).....                                                                                                                                                                                                      | 3                  | 3                                            |
| 556       | Contactor switch (3-pole).....                                                                                                                                                                                                              | 1                  | 1                                            |
| 557       | Automatic switch (reverse current relay).....                                                                                                                                                                                               | 1                  | 1                                            |
| 558       | Binding posts (No. 14-20 brass, with wing nuts and washers).....                                                                                                                                                                            | 8                  | 8                                            |
| 559       | Phenolic stand-offs for binding posts (1 inch high).....                                                                                                                                                                                    |                    | 8                                            |
| 560       | Knife switches, double-pole single-throw, 125-volt, 15-ampere, each<br>with two 15-ampere fuses and fuse clips.....                                                                                                                         | 3                  |                                              |
| 561       | Circuit-breakers, 0322-10, Heinemann Electric Co., Trenton, N. J.,<br>or equal.....                                                                                                                                                         |                    | 3                                            |
| 562       | Rheostats, 12.5 ohms (approx.); 12-ampere capacity on first step,<br>tapering to 3.4 amperes in 33 or more steps (Ward Leonard E. D.<br>28890 or equal).....                                                                                | 3                  | 3                                            |
| 563       | Wire, stranded copper, equivalent to No. 12 A. W. G., rubber in-<br>sulated and braided.                                                                                                                                                    |                    |                                              |
| 564       | Screws, brass, black nickel finish, peined over to prevent loosening,<br>except parkerized steel screws holding panel in cabinet.                                                                                                           |                    |                                              |
|           | <i>ax.</i> The following items are not issued with the set but are desirable accessories:<br>1 can, 1-gallon, with flexible spout.<br>1 cup, measuring ½ pint (PE-HA-43).<br>1 oiler, small (1 additional oiler for priming with PE-HA-43). |                    |                                              |

[A. G. 062.11 (5-9-41).]

BY ORDER OF THE SECRETARY OF WAR:

G. C. MARSHALL,  
*Chief of Staff.*

OFFICIAL:

E. S. ADAMS,  
*Major General,*  
*The Adjutant General.*

DISTRIBUTION:

B2 (2); IR 2, 4 (2); IBn 4, 6, 11 (3); IC 2, 4, 6, 11 (3).  
(For explanation of symbols see FM 21-6.)









